

# Compact-Line Healthcare






GB

Operating instructions



cBoxX 60  
cBoxX 70  
cBoxX 80  
cBoxX 100  
cBoxX 120

**Table 1: Contact details**

<p>Manufacturer</p>	<p>ait-deutschland GmbH          Industriestraße 3          95359 Kasendorf          Germany          T +49 9228 9977 0          F +49 9228 9977 149          E <a href="mailto:info@kkt-chillers.com">info@kkt-chillers.com</a>          W <a href="http://www.kkt-chillers.com">www.kkt-chillers.com</a></p>
<p>Service</p>	<p>ait-deutschland GmbH          Industriestraße 3          95359 Kasendorf          Germany          T +49 9228 9977 7190 *          F +49 9228 9977 7474          E <a href="mailto:service@kkt-chillers.com">service@kkt-chillers.com</a>          W <a href="http://www.kkt-chillers.com">www.kkt-chillers.com</a></p> 
<p>Service USA</p>	<p>KKT chillers, Inc.          765 Dillon Drive          Wood Dale          IL 60191          TF +1 833 558 4357 *          F +1 847 734 1601          E <a href="mailto:techsupport@kkt-chillersusa.com">techsupport@kkt-chillersusa.com</a></p> 
<p>Service East Asia</p>	<p>KKT chillers East Asia          Sales and Service Office          5-1-D, No. 333 Xingpu Road          Modern Industrial Park          Suzhou 215021, Jiangsu Province, P.R.C.          S +86 512 6790 3091*          F +86 512 6287 1077          E <a href="mailto:service@kkt-chillerscn.com">service@kkt-chillerscn.com</a></p> 

The operating instructions in digital form can be requested under (E [info@kkt-chillers.com](mailto:info@kkt-chillers.com))

## Introduction


These operating instructions have been drawn up by KKT chillers. They contain all important information and instructions for the installation and safe operation of the chiller. It also contains suggestions on how to prevent or correct faults.

Please take enough time to carefully read this instruction manual and to process all the information that it contains. For further questions, please contact the KKT chillers Service Team by means of the aforementioned contact details.

If properly used for its intended use and correctly maintained, the chiller ensures sustained, fault-free operation. The methods and procedures described in this manual were designed to help you identify problems at an early state and to initiate corresponding countermeasures.

By observing the described maintenance program, you ensure that the reliability and safety of the machine is maintained. Plus this keeps operating costs low and increases the service life of the components.

To ensure that the performance of your chiller is not impaired, we recommend that you only use original spare parts from KKT chillers. By doing so, you ensure the reliability and quality of the machine.

	<p><b>ATTENTION! A black exclamation mark on a yellow background in a triangle indicates important information and instructions to which you must pay particular attention and must always follow.</b></p>
---	--

KKT chillers reserves the right to change technical data without prior announcement. Illustrations in this document are not set to scale!

As the devices of the Compact-Line can be adapted project specifically, this document contains only information that is of general relevance for all devices of the series.

All project-specific data is enclosed with the unit in separate summary documentation.

- Machine configuration
- Parameter list
- P&I diagram
- Pump characteristic curve(s)
- Circuit diagram
- All other project-specific details

## Contents

Introduction.....	3
1. Product description .....	7
1.1. Intended use .....	7
1.2. Elements.....	13
1.3. Explanation of terms.....	14
2. Function and main components.....	14
2.1. Compressor .....	15
2.2. Evaporator .....	15
2.3. Condenser .....	15
2.4. Expansion valve .....	15
2.5. Refrigerant.....	15
2.6. Oil.....	16
2.7. Filter dryer .....	16
2.8. Pressure sensors .....	16
2.9. Temperature sensors.....	16
2.10. Control unit / main circuit board.....	16
2.11. Display .....	16
2.12. Control cabinet.....	16
2.13. Pump.....	17
2.14. Fan .....	17
2.15. Closed cold water circuit .....	17
2.16. Materials used in the water circuit .....	18
2.17. Water quality .....	19
2.18. Permitted coolant media .....	20
3. Options and accessories .....	20
3.1. Heater for the compressor and control cabinet.....	20
3.2. Insulating cold pipes.....	21
3.3. Pump redundancy.....	21
3.4. Phase monitoring.....	21
3.5. Hot gas bypass for output control <1K.....	21
3.6. Low-temperature package (ambient temperature < -25 ° C).....	21
3.7. Levelling feet (accessories).....	21
3.8. Filter assembly group coolant circuit (accessories).....	22
3.9. Anybus-Gateway (accessories).....	22
3.10. Remote control panel (accessories) .....	23
3.11. Special languages (accessories).....	23
3.12. Seaworthy crate packaging (accessories) .....	23
3.13. Earthquake kit (accessories).....	24
3.14. CIP Chiller interface panel (accessories).....	25
4. Safety.....	25
4.1. General information.....	25
4.2. Hazard warnings .....	25
4.3. Residual energy.....	28

4.4.	Safety devices, guards and safeguards .....	29
4.4.1.	High-pressure limiter.....	29
4.4.2.	High-pressure monitoring.....	30
4.4.3.	Low-pressure monitoring.....	30
4.4.4.	Flow monitoring.....	30
4.4.5.	Personal protective equipment when operating the machine .....	30
4.5.	Personal protective equipment for servicing work .....	31
4.6.	Airborne sound emissions.....	32
4.7.	Notes on reducing noise and vibration.....	32
4.7.1.	Noise .....	32
4.7.2.	Vibration.....	33
4.8.	Residual risks.....	33
4.8.1.	Electrical .....	33
4.8.2.	Mechanical .....	33
4.8.3.	Chemical .....	33
4.8.4.	Other .....	33
4.9.	Dangerous substances.....	34
4.9.1.	Refrigerant R410A .....	34
4.9.2.	Öl POE 160SZ.....	35
4.10.	Reasonably foreseeable misuse.....	36
4.11.	Information for emergencies.....	37
5.	Handling and storage .....	37
5.1.	Dangerous goods.....	37
5.2.	Transport .....	37
5.2.1.	Forklift truck .....	38
5.3.	Unpacking.....	39
5.4.	Storage .....	39
6.	Installation .....	40
6.1.	Overview .....	40
6.2.	Installation site.....	40
6.2.1.	General information .....	40
6.2.2.	Minimum room volume.....	40
6.2.3.	Ambient temperature.....	41
6.2.4.	Effect of surrounding air flow .....	41
6.2.5.	Minimum clearances .....	41
6.2.6.	Surface and foundation .....	42
6.2.7.	Stability .....	42
6.2.8.	Levelling.....	42
6.2.9.	Vibration isolation .....	42
6.2.10.	Installation.....	42
6.2.11.	Hydraulic installation .....	43
6.2.12.	Frost protection measures .....	43
6.2.13.	Flushing the cold water circuit .....	43
6.2.14.	Filling.....	44
6.2.15.	Venting.....	44

6.2.16.	Electrical installation.....	45
7.	Commissioning .....	46
7.1.	Installation checklist.....	46
8.	Operation.....	47
8.1.	Switching on .....	47
8.2.	Selecting the operating mode .....	47
8.3.	External release .....	47
8.4.	Control .....	48
8.5.	Control panel.....	48
8.5.1.	Start screen .....	50
8.5.2.	Main menu.....	51
8.5.3.	Information .....	51
8.5.4.	Settings.....	53
8.5.5.	Alarm menu .....	54
8.6.	Parameters.....	54
8.7.	Controller description .....	55
8.7.1.	Switching the chiller on/off .....	55
8.7.2.	Cold water feed temperature control.....	56
8.7.3.	Compressor control.....	57
8.7.4.	Fan speed control .....	57
8.7.5.	Electronic expansion valve control.....	57
8.7.6.	Temperature limit monitoring.....	57
8.7.7.	Group fault alarm .....	58
8.8.	Operating modes.....	58
8.8.1.	ECO mode .....	58
8.8.2.	Comfort mode.....	58
9.	Cleaning .....	58
9.1.	Air filter mat.....	58
9.2.	Condenser .....	58
9.3.	Water filter.....	58
9.4.	Complete cleaning of the cold water circuit.....	59
10.	Service.....	59
10.1.	Maintenance .....	59
10.2.	Disposal.....	59
10.3.	Spare parts.....	60
11.	Decommissioning/Taking out of service.....	60
11.1.	Draining .....	61
12.	Recycling.....	61
13.	Products, solutions and services.....	62
I.	Menu navigation.....	63
II.	Troubleshooting.....	76
III.	II. Maintenance intervals in accordance with the VDMA.....	88
IV.	Product registration .....	91

## 1. Product description

Please read all the points in these operating instructions before starting up the machine. You should pay particular attention to the points on safety, commissioning/startup and operation. Should you have any further questions concerning your machine, please contact the KKT chillers Service Team (*see Contact details*).

### 1.1. Intended use




The cBoxX is a factory-tested, fully automatic compressor chiller. The machine is only used for cooling liquids in accordance with EN 378-1. A sufficient supply of cooling air must be provided. Only approved liquids may be used. The cBoxX corresponds to protection class IP 54 (when the housing is closed) and is suitable for both indoor and outdoor installation (observe option packages).

The operator is responsible for complying with the specified operating, servicing and maintenance conditions according to these operating instructions.

The owner of the chiller, not the manufacturer, is responsible and liable for all personal injuries and damage to property caused by improper use of the unit (misuse).

Table 2 contains the general safety instructions of the chiller. These instructions are attached to the machine in a clear and readily visible position. A complete description of all hazard warnings is given in Chapter **4.2 Hazard warnings**.

Table 2: Safety instructions

	Note and follow the instructions for use!
	Before opening the machine, disconnect the machine from the power supply. After disconnecting the machine from the power supply, always wait for at least 5 minutes before opening it.
	Beware of dangerous electrical voltage! If the machine is only turned off by means of the main switch, some of the terminals in the control cabinet will still be under dangerous voltage.

## Technical data

**Table 3: Technical data**

Chillertyp	cBoxX 60	cBoxX 60	cBoxX 60	cBoxX 60	cBoxX 60	cBoxX 60	cBoxX 60	cBoxX 60	cBoxX 60
SAP-Nummer	909060-00238	909060-00239	909060-00240	909060-00241	909060-00242	909060-00243	909060-00244	909060-00377	909060-00424
Refrigerating capacity @ tw2=13°C / tu=45°C	41kW	41kW	41kW	41kW	41kW	41kW	41kW	41kW	41kW
Ambient temperature range	-25 - +45 °C	-25 - +45 °C	-40 - +45 °C	-25 - +45 °C	-25 - +45 °C	-25 - +45 °C	-40 - +45 °C	-25 - +45 °C	-25 - +45 °C
Hermetically sealed refrigeration circuit	no								
Refrigerant	R410A								
GWP	2088								
Refrigerant capacity	7kg								
CO2 equivalent	14,6 t CO2								
Cooling medium	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 50Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 50Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN
Liquid feed temperature	13 °C								
Target constancy	+/-2K								
Coolant circulation	5,0 m³/h								
Free pump pressure (min)	2,8bar	2,8bar	2,8bar	2,8bar	2,8bar	5bar	5bar	2,8bar	5bar
Operating voltage	400V/3/50Hz	400V/3/50Hz	400V/3/50Hz	400V/3/60Hz	460V/3/60Hz	460V/3/60Hz	460V/3/60Hz	460V/3/60Hz	460V/3/60Hz
Protection class	IP54								
Air flow rate (max.)	20.000 m³/h								
Sound pressure level at 5 m distance	69 dB(A)								
Height	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm
Width	830 mm	830 mm	830 mm	830 mm	830 mm	830 mm	830 mm	830 mm	830 mm
Length	1240 mm	1240 mm	1240 mm	1240 mm	1240 mm	1240 mm	1240 mm	1240 mm	1240 mm
Net weight without refrigerant	515 kg	540 kg	515 kg	515 kg	540 kg	540 kg	540 kg	540 kg	584 kg
Pumps Quantity	1	2	1	1	2	2	2	2	2
Certificates	CE	CE	CE	CE	CE	CE/UL/CSA	CE/UL/CSA	CE	CE/UL/CSA/ seismic



Chillertyp	cBoxX 70	cBoxX 70	cBoxX 70	cBoxX 70	cBoxX 70	cBoxX 70	cBoxX 70
SAP-Nummer	909070-00245	909070-00246	909070-00247	909070-00248	909070-00249	909070-00255	909070-00425
Refrigerating capacity @ tw2=13°C / tu=45°C	45kW	45kW	45kW	45kW	45kW	45kW	45kW
Ambient temperature range	-25 - +55°C	-25 - +55°C	-25 - +55°C	-25 - +55°C	-25 - +55°C	-25 - +55°C	-25 - +55°C
Hermetically sealed refrigeration circuit	no						
Refrigerant	R410A						
GWP	2088						
Refrigerant capacity	8kg						
CO2 equivalent	16,7 t CO2						
Cooling medium	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 35Vol% AFN
Liquid feed temperature	13°C						
Target constancy	+/-2K						
Coolant circulation	5,0 m³/h						
Free pump pressure (min)	2,8bar	2,8bar	2,8bar	2,8bar	5bar	2,8bar	5bar
Operating voltage	400V/3/50Hz	400V/3/50Hz	400V/3/60Hz	460V/3/60Hz	460V/3/60Hz	400V/3/60Hz	460V/3/60Hz
Protection class	IP54						
Air flow rate (max.)	36.500 m³/h						
Sound pressure level at 5 m distance	71 dB(A)						
Height	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm
Width	830 mm	830 mm	830 mm	830 mm	830 mm	830 mm	830 mm
Length	1840 mm	1840 mm	1840 mm	1840 mm	1840 mm	1840 mm	1840 mm
Net weight without refrigerant	665 kg	680 kg	680 kg	680 kg	680 kg	665 kg	724 kg
Pumps Quantity	1	2	2	2	2	1	2
Certificates	CE	CE	CE	CE	CE/UL/CSA	CE	CE/UL/CSA/ seismic


Chillertyp	cBoxX 80	cBoxX 80
SAP-Nummer	909080-00284	909080-00529
Refrigerating capacity @ tw2=9°C / tu=45°C	50kW	59 kW
Ambient temperature range	-25 - +50 °C	-25 - +50 °C
Hermetically sealed refrigeration circuit	no	no
Refrigerant	R410A	
GWP	2088	
Refrigerant capacity	8kg	8kg
CO2 equivalent	16,7 t CO2	16,7 t CO2
Cooling medium	Water with 40Vol% AFN	Water with 40Vol% AFN
Liquid feed temperature	9	
Target constancy	+/-2K	
Coolant circulation	7,8 m³/h	7,2 m³/h
Free pump pressure (min)	4,5 bar	5,5 bar
Operating voltage	400V/3/50Hz	400V/3/60Hz
Protection class	IP54	
Air flow rate (max.)	36.500 m³/h	36.500 m³/h
Sound pressure level at 5 m distance	71 dB(A)	71 dB(A)
Height	2030 mm	2030 mm
Width	830 mm	830 mm
Length	1840 mm	1840 mm
Net weight without refrigerant	680 kg	680 kg
Pumps Quantity	2	2
Certificates	CE	CE

Chillertyp	cBoxX 100	cBoxX 100	cBoxX 100	cBoxX 100	cBoxX 100
SAP-Nummer	909100-00468	909100-00469	909100-00470	909100-00218	909100-00510
Refrigerating capacity @ tw2=9°C / tu=45°C	63 kW	63 kW	63 kW	60 kW	73 kW
Ambient temperature range	-25 - +50°C	-25 - +50°C	-40 - +50°C	-25 - +50°C	-25 - +50°C
Hermetically sealed refrigeration circuit	no				
Refrigerant	R410A				
GWP	2088				
Refrigerant capacity	8	8	8	8	8
CO2 equivalent	16,7 t CO <sub>2</sub>	16,7 t CO <sub>2</sub>	16,7 t CO <sub>2</sub>	16,7 t CO <sub>2</sub>	16,7 t CO <sub>2</sub>
Cooling medium	Water with 35Vol% AFN	Water with 35Vol% AFN	Water with 50Vol% AFN	Water with 40Vol% AFN	Water with 40Vol% AFN
Liquid feed temperature	9°C				
Target constancy	+/-2K				
Coolant circulation	6,0 m <sup>3</sup> /h	6,0 m <sup>3</sup> /h	6,0 m <sup>3</sup> /h	7,8 m <sup>3</sup> /h	9,1 m <sup>3</sup> /h
Free pump pressure (min)	5,0 bar	5,0 bar	5,0 bar	5,9 bar	5,5 bar
Operating voltage	460V/3/60Hz (+/-10%)			400V/3/50Hz (+/-10%)	400V/3/60Hz (+/-10%)
Protection class	IP54				
Air flow rate (max.)	36.500 m <sup>3</sup> /h	36.500 m <sup>3</sup> /h	36.500 m <sup>3</sup> /h	36.500 m <sup>3</sup> /h	36.500 m <sup>3</sup> /h
Sound pressure level at 5 m distance	71 dB(A)	71 dB(A)	71 dB(A)	71 dB(A)	71 dB(A)
Height	2030 mm	2030 mm	2030 mm	2030 mm	2030 mm
Width	830 mm	830 mm	830 mm	830 mm	830 mm
Length	1840 mm	1840 mm	1840 mm	1840 mm	1840 mm
Net weight without refrigerant	701 kg	751 kg	701 kg	. 751 kg	751 kg
Pumps Quantity	2	2	2	2	2
Certificates	UL/CSA	UL/CSA/seismic*	UL/CSA	CE	CE

\* seismic certification is pending

Chillertyp	cBoxX 120	cBoxX 120	cBoxX 120	cBoxX 120
SAP-Nummer	909120-00313	909120-00528	909120-00471	909120-00472
Refrigerating capacity @ tw2=9°C / tu=45°C	74 kW	88 kW	75 kW	75 kW
Ambient temperature range	-25 - +50°C	-25 - +50°C	-25 - +50°C	-40 - +50°C
Hermetically sealed refrigeration circuit	no			
Refrigerant	R410A			
GWP	2088			
Refrigerant capacity	17	17	17	17
CO2 equivalent	35,5 t CO <sub>2</sub>	35,5 t CO <sub>2</sub>	35,5 t CO <sub>2</sub>	35,5 t CO <sub>2</sub>
Cooling medium	Water with 40Vol% AFN	Water with 40Vol% AFN	Water with 35Vol% AFN	Water with 50Vol% AFN
Liquid feed temperature	9°C			
Target constancy	+/-2K			
Coolant circulation	7,8 m <sup>3</sup> /h	10,8 m <sup>3</sup> /h	7,8 m <sup>3</sup> /h	7,8 m <sup>3</sup> /h
Free pump pressure (min)	5,9 bar	5,5 bar	5,0 bar	5,0 bar
Operating voltage	400V/3/50Hz (+/-10%)	400V/3/60Hz (+/-10%)	460V/3/60Hz (+/-10%)	460V/3/60Hz (+/-10%)
Protection class	IP54			
Air flow rate (max.)	45.550 m <sup>3</sup> /h	45.550 m <sup>3</sup> /h	45.550 m <sup>3</sup> /h	45.550 m <sup>3</sup> /h
Sound pressure level at 5 m distance	66 dB(A)	66 dB(A)	66 dB(A)	66 dB(A)
Height	2030 mm	2030 mm	2030 mm	2030 mm
Width	1100 mm	1100 mm	1100 mm	1100 mm
Length	2665 mm	2665 mm	2665 mm	2665 mm
Net weight without refrigerant	1046 kg	1046 kg	1046 kg	1046 kg
Pumps Quantity	2	2	2	2
Certificates	CE	CE	UL/CSA	UL/CSA

## 1.2. Elements



1	Cover panel operating side top		a	Safety instructions
2	Cover panel operating side bottom		b	Water connections
3	Cover panel service side top		c	Nameplate
4	Cover panel service side bottom		d	Display
5	Cover panel condenser protection grilles		e	Main switch
6	Cover panels hydraulics			

### 1.3. Explanation of terms


For the sake of better understanding, we have listed some relevant terms that are used frequently in this document.

**Table 4: Explanation of terms**

Term	Explanation
Application	The source of heat hydraulically connected to the chiller.
Process circuit	Application and piping to the chiller.
Cold water circuit	Process circuit and chiller in hydraulic piping.
Cold water	Refrigerant in cold water circuit.
Cooling air	Heat absorbing ambient air drawn through the machine.
Net weight	Machine ready for operation without cooling water.
Gross weight	Machine ready for operation with cooling water.

## 2. Function and main components

The chiller consists of the main components compressor, condenser, expansion valve, evaporator, which are arranged in a circuit (*Illustration 1*). Refrigerant circulates in this circuit. In the evaporator, it absorbs heat from the cold water and emits it in the condenser into the drawn in air.



**Figure 1: C6848 refrigeration diagram**

In addition, diverse pressure and temperature sensors, a control unit, a high-pressure switch, one or more pumps and one or more fans are also installed for control and operation of the chiller.

## 2.1. Compressor

The compressor generates the needed pressure difference for evaporation and condensation between heat sink and heat source in the refrigerant circuit. Vaporised refrigerant coming from the evaporator is drawn in and compressed in the compressor to the condensing pressure.

The compressors used work on the basis of the scroll principle. Scroll compressors are maintenance-free, quiet and have a very high degree of efficiency.

The flow temperature is controlled by switching on or off one or more compressors (see **8.7.4 Compressor control**). Sequential changeover ensures that all compressors are loaded uniformly.

## 2.2. Evaporator

The evaporator is a plate heat exchanger that transfer heat from the cold water to the refrigerant. In order for the transfer of heat to take place, the refrigerant in the evaporator must have a lower temperature than the cold water and changes its physical state upon heat absorption from liquid to gaseous.

If the cold water is polluted, deposits can accumulate on the transfer surfaces of the evaporator. This impairs the transfer of heat to the refrigerant and has negative effects on the refrigerating capacity of the machine. Therefore always make sure to use the prescribed water quality and do not make use of any other additives than prescribed.

## 2.3. Condenser

The condenser is a microchannel heat exchanger that transfers heat from the refrigerant to the ambient air. In order for the transfer of heat to take place, the refrigerant in the condenser must have a higher temperature than the drawn-in ambient air changes its physical state upon heat dissipation from gaseous to liquid.

Contaminated cooling air can cause deposits to accumulate on the condenser surface. This impairs the transfer of the heat to the refrigerant. This restricts the operating limit of the machine and reduces the refrigerating capacity of the machine. How to clean the condenser is described in **Chapter 9 Cleaning**. If you operate your chiller in an environment contaminated with dust or oil vapours, make use of the optionally available air filter mat (see **3.19 Air filter mat**).

## 2.4. Expansion valve

The expansion valve regulates the admission of liquid refrigerant to the evaporator and restricts the pressure of the refrigerant before entering the evaporator. In this process, the refrigerant cools down to the evaporating temperature.

The expansion valve used in the machine is regulated electronically. The electronic regulation ensures that the evaporator is constantly optimally supplied with refrigerant. This improves the COP (coefficient of performance) and reduces pressure fluctuations in the refrigeration circuit.

## 2.5. Refrigerant

The refrigerant R410A circulates in the refrigeration circuit. It "transports" the heat from the evaporator the condenser and continuously changes its physical state in doing so.

R410A is a fluorinated greenhouse gas consists of the zeotropic mixture 50% R32 and 50% R125 with virtually negligible temperature glide. R410A has a very high volumetric cooling capacity and

has no ozone depletion potential (ODP=0). A corresponding safety data sheet can be requested from our KKT chillers Service Team (**see: Contact details**).

## **2.6. Oil**

The compressor components subject to friction are lubricated by oil that is added to the refrigerant at the factory. Polyolester-160SZ is used for this purpose. The oil is soluble in the refrigerant and distributes itself with it throughout the entire refrigeration circuit. The total oil quantity of the specific unit can be taken from the technical data. A corresponding safety data sheet can be requested from our KKT chillers Service Team (**see: Contact details**).

## **2.7. Filter dryer**

The task of the filter dryer is to absorb any contamination or moisture from the cooling circuit. Both refrigerant and oil are hygroscopic. When installing the refrigeration circuit, the oil may absorb moisture. This moisture can lead to corrosion and impair the cooling process. The filter dryer bonds this moisture and also has a mechanical filter effect. If work is being performed on the refrigeration circuit, for which it has to be opened, the filter dryer (cBoxX 30 – cBoxX 100) must be replaced.

## **2.8. Pressure sensors**

The pressure sensors used are compact pressure transmitters with piezoresistive measurement cell. The sensors continuously record the system pressure at various locations in the refrigerant and cold water circuits. The values are used to regulate the system and for visualisation on the controller display.

## **2.9. Temperature sensors**

The temperature sensors employed are equipped with a platinum measurement cell. The sensors continuously record the temperature at various locations in the refrigerant and cold water circuits. The values are used to control the system.

## **2.10. Control unit / main circuit board**

The control unit is a control that is programmed at the factory. This is where all system-technical measurement values and information come together. In addition, the electrical components are controlled via algorithms.

## **2.11. Display**

The display is used to visualise the necessary information and processes of the system for the user. Plus, it can be used to make entries. The display communicates with the control unit. Further information on operation can be found in Chapter **8.5 Control panel**.

## **2.12. Control cabinet**

The control cabinet conforms to the requirements of EN 60204 and contains the electrical and electronic components for controlling the chiller. The control cabinet can be accessed by removing the operating panel. To prevent damage to the main switch when disassembling the side panel, it must be tilted at least 10 cm before it can be removed. It can be opened by means of a standard two-way key. A corresponding circuit diagram is included with the device.






Figure 2: Demounting the side panel

### 2.13. Pump

The pump of the chiller provides for the necessary circulation of the cold water.

### 2.14. Fan

The fan draws in the cooling air from the environment via the condenser and discharges the heated air upward from the chiller. To prevent injuries, the fan is protected against accidental contact by protective grilles. The fan's speed is variable and is regulated from the main circuit board. The speed of the fan is essentially determined by the condensing pressure. The fan is protected against thermal overload. In units with two fans the speed of fan1 is always the same as the speed of fan2.

### 2.15. Closed cold water circuit

Cold water is conveyed through the process circuit by means of the internal pump. In the process circuit, the cold water absorbs heat. The circuit closes when the cold water is conveyed back into the chiller. It goes through the evaporator in which it discharges the heat. Then the cycle starts again.

Furthermore, the closed system is designed with a membrane expansion vessel that is under a certain initial pressure depending on the system volume. The membrane expansion vessel balances out the temperature fluctuations and the associated system pressure in the cold water circuit. If the water pressure increases, the membrane expansion vessel absorbs the expansion volume of the water. If the water temperature decreases, the membrane expansion vessel takes the expansion water back to the cold water circuit.

## 2.16. Materials used in the water circuit

In the standard version, the material compilation is depicted as shown in Table 5:

**Table 5: Materials used in the standard version**

<b>Component</b>	<b>Material (cBoxX 60 – cBoxX120)</b>
Unit connections	V2A 1.4305
Evaporator	V2A 1.4301 and copper (99.9%)
Pump	Grey cast iron and V2A 1.4301
Mechanical seal	EPDM
Sealing plugs yellow	Polyamide PA 6
Sealing plugs black	Polyoxymethylene (POM)
Bends, tees, couplings	Gunmetal CC499K
Fittings	V4A 1.4408
Hose nozzle	Brass, nickel-plated
Temperature sensor PT1000	V2A 1.4301
Pressure sensor XSK AC10I-U188	V2A 1.4301

## 2.17. Water quality

The following limit values must be adhered to to ensure the safe operation of the devices:

**Table 6: Water quality**

Property / Constituents	Unit	Value range Standard model	Value range Non-ferrous metal version
pH-value (20°C)	-	7-9	6-9
Saturation index	-	-0.2 < 0 < +0.2	-0.2 < 0 < +0.2
Conductivity	µS/cm	80-500	5-500
Water hardness	°dH	<5.6	<5.6
Carbonate hardness	mol/m <sup>3</sup>	<0.5	<0.5
Total germ count	K/ml	<10,000	<10,000
Grain size	µm	< 250	< 250
Glycole fraction (AFN)	Vol%	20-40	20-40
Oil fraction	Vol%	0	0
Chloride(Cl <sup>-</sup> )	mg/l	<50	<50
Sulphate	mg/l	<50	<50
Nitrate	mg/l	<100	<100
Copper	mg/l	<0.1	<0.1
Iron	mg/l	<0.2	<0.2
Free carbonic acid	mg/l	<20	<20
Manganese	mg/l	<0.1	<0.1
Ammonia	mg/l	<2	<2
Free chloride	mg/l	<0.5	<0.5
Sulphide	mg/l	<0.03	<0.03

To prevent clogging of the plate heat exchangers, the prescribed limit values must be observed.

Furthermore, any occurrence of mucilage bacteria in the cooling water must be ruled out. If this is not possible, KKT chillers can suggest or provide a suitable inhibitor on the basis of a biological water analysis to remove the mucilage agents.

## 2.18. Permitted coolant media

Permitted are water fluids and mixtures consisting of water / Antifrogen N (AFN) or water/ Antifrogen L (AFL) pursuant to the specification defined in **Chapter 2.17 Water quality**. The following table depicts the definitions of the mixing ratios between water and anti-freeze AFN or AFL. To maintain the performance capacity of your machine and to prevent damage to the components, these values must be complied with to the greatest extent possible.


	<b>ATTENTION! Do not use mixtures of different anti-freeze products. This can lead to undesired chemical reactions as well as silting.</b>
---	--

Table 7: Mixing ratios AFN and AFL (or comparable)

Setting	Frost-free to	AFN mixing ratio	AFL mixing ratio
Glycol 35 - 38 %	-25 °C	35 - 38 %	37 - 40%
Glycol 50 %	-40 °C	50 %	52 %

## 3. Options and accessories

The chiller can be equipped in the factory with the options described in the following.

The positions marked with "accessory" are included with the device, unattached, and can be re-ordered at any time with the respective product number. The installation of the accessory is the responsibility of the installer of the machine. You can also ask our KKT chillers Service Team to arrange for this installation (see **Contact details**).

Information on the features of your machine can be found in the separately enclosed summary documentation.

### 3.1. Heater for the compressor and control cabinet

The oil sump heater prevents the deposit of refrigerant in the oil when the temperature is low. When the compressor is started up this refrigerant would be liberated from the oil as gas and make the oil foam up. Under these conditions the lubrication of components subject to friction in the compressor would be poor, which could lead to the damage of the compressor.

The control cabinet heater is thermostatically controlled and prevents moisture from the drawn-in ambient air in the event of lower ambient temperatures from condensing on electrical and electronic components of the control cabinet and hence from damaging them.

To enable the activation of both heaters, the chiller may not be disconnected from the power supply (**8.2 Selecting the operating mode**).

### 3.2. Insulating cold pipes

To prevent condensation on cold chiller pipes, where high temperature differences exist between the surroundings and cold water flow and taking into account the relative humidity the option of insulation of the cold pipes must be specified.

### 3.3. Pump redundancy

Depending on the device model, a second pump can be used for redundancy reasons. If a second pump is included, the pumps are switched at regular intervals (can be set e.g. to every 24h) in order to increase the service life of the pump. This means that if a pump fails, the second pump is activated automatically and therefore ensures secure operation.

### 3.4. Phase monitoring

Compact-Line devices can also be optionally equipped so-called phase monitoring. It monitors phase sequence, phase failure, under voltage and asymmetry and covers a voltage range of 200-690V. If the respective predefined limits are exceeded the system switches off and protects the electrical components installed in the unit.

### 3.5. Hot gas bypass for output control <1K

If a more precise target constant than  $\pm 1$  Kelvin is required, the chiller can be equipped with an output control. In this case the output of the refrigeration circuit is adjusted to the cooling demand by an electronically controlled valve. Unlike the standard control by switching compressors on or off, a higher target constant is achieved by the continuous regulation of the valve.

### 3.6. Low-temperature package (ambient temperature < -25 ° C)

If the chiller is operated at ambient temperatures below -25 °C, the low-temperature package has to be installed. With the use of additional heating and two non-return valves, this ensures a stable refrigerant pressure in the refrigeration circuit at temperatures below -25 °C.

### 3.7. Levelling feet (accessories)

The levelling feet are used for vibration isolation and for height adjustment. They consist of a threaded rod and a grey cast iron shell with an elastic element attached. The threaded rod enables the height to be adjusted and compensates for floors sloping by up to 5°. The elastic element has a slip-resistant covering. **Figure 3, Figure 4 and Figure 5** show the installed machine foot – the technical drawing is given in the appendix. (Attention: Not allowed in combination with the earthquake kit)




Figure 3: Machine base (foot) – Outside view



Figure 4: Machine base (foot) - mounting on the baseplate



Figure 5: Seismic feet are used for seismic and high wind gust regions

### 3.8. Filter assembly group coolant circuit (accessories)

The water filter protects the cold water circuit against dirt. The set, consisting of a filter, fitting and two shut off valves, is enclosed with the chiller in a separate pack and must be fitted onto the cold water inlet of the chiller from the outside when the chiller is installed.

### 3.9. Anybus-Gateway (accessories)

The Anybus-Gateway is ready mounted in the switch cabinet and can be used as an interface for processing all chiller signals. Therefore the following processing protocols are available depending on the customer specification:

A Modbus TCP communication is already included on the display pcb as a standard feature. An Anybus gateway is not required.

### **3.10. Remote control panel (accessories)**

In the event that the chiller shall be operated not from the machine itself but from a different operating location, the chiller can be delivered with a remote control panel. Thereby the same display that is already installed in the chiller is mounted together with a rail to the operating voltage supply in one miniature housing. The remote control panel can be connected to the chiller via the RS485 interface and takes over the complete function of the controller in the main device. By setting the accordant bridge in the control cabinet cabinet of the main device, the required operating place can be chosen.

### **3.11. Special languages (accessories)**

These instruction manuals are provided in German, English, French and Spanish. Other languages are available on request.

### **3.12. Seaworthy crate packaging (accessories)**

Seaworthy crates for the Compact-Line are produced according to International Standards for Phytosanitary Measures with packaging made of solid wood (ISPM 15). This means that the crates are made of heat-treated solid wood which has been stripped of its bark. Only wood-based materials, such as OSB boards, are used. In addition, all crates are marked with the IPPC logo and registration number. The units are fixed in the crate with the help of coach bolts, ring nuts and polyester straps and are packed in a sea air consistent foil with desiccant. The components used to pack the units can be dismantled using a cross-head screwdriver. Please note the changed transport dimensions.

**3.13. Earthquake kit (accessories)**

In the event that your chiller is to be operated in areas of tectonic activity, your device can be supplied with the earthquake kit accessory. Here the chiller is equipped with additional reinforcement bars as well as specially non-adjustable machine bases (feet). *Figures 6 and 7* show the assembled earthquake kit - detailed assembly instructions are included with the accessory.




Figure 6: Earthquake kit cBoxX 60




Figure 7: Earthquake kit cBoxX 70 - 100



### 3.14. CIP Chiller interface panel (accessories)

The CIP accessory is a transfer station that can be installed in the customer's cold water circuit. The transfer station is made of Üsheet steel and contains a water filter, a flow rate indicator, inlet and outlet valve, pressure and temperature displays as well as a connection to an emergency cooling system. *Figures 6 and 7* show the assembled earthquake kit - detailed assembly instructions are included with the accessory.




Figure 8: Chiller Interface Panel

## 4. Safety

The chiller, within the sense of its intentional use, is designed to operate safely, provided also that the instructions concerning transport, installation, commissioning/startup and maintenance given in these operating instructions are complied with.












### 4.1. General information

The chiller contains a high-pressure circuit. The maximum pressure that occurs is 45 bar. Even when inactive or disconnected from the power supply the circuit is still under pressure.

### 4.2. Hazard warnings







A number of warning labels are applied to the machine. Keep these warnings clean at all times. Damaged or missing warnings must be replaced.

Table 8: Definition of the safety symbols

	Observe the instruction manual!
	Before opening the machine, disconnect the machine from the power supply. The machine may only be opened 5 minutes after it has been disconnected from the power supply.
	Beware of dangerous electrical voltage! If the machine is only turned off by means of the main switch, some of the terminals in the control cabinet will still be under dangerous voltage.
	Wear foot protection!
	Wear hand protection!
	Wear eye protection!
	Wear protective clothing!
	Beware of hot surface!
	Beware of cold surface!
	ATTENTION!
	Contains pressurised gas!

The following hazard warnings apply in particular to the machine:

Table 9: Hazard warnings

	<b>ATTENTION! Work on the chiller must be carried out by properly qualified, competent personnel!</b>
	<b>The surfaces of pipes and components of the refrigerant and cold water circuit and electrical equipment can be very hot during operation and even for a while after.</b>
	<b>The surfaces of pipes and components of the refrigerant and cold water circuit and electrical equipment can be very hot during operation and even for a while after.</b>
	<b>ATTENTION! Pipes and components of the refrigerant and cold water circuit are pressurised.</b>
	<b>ATTENTION! Do not undo the system parts. Risk of injury on contact.</b>
	<b>ATTENTION! Only use the specified liquids!</b>

### 4.3. Residual energy

Even if all the hazard warnings in Chapter 4.2 are taken into account, the following residual energy situations can result in a hazard:

- Rotational energy of the decelerating fan
  - Despite the installed protective grille, hair or pieces of clothing can still be drawn in and caught.
- Hot surfaces on machine parts
  - Especially the compressor head and the hot gas pipe and the condenser can still be very hot for some time after the machine has been switched off. Temperatures within the range from 60°C to 90°C are possible.
- Dangerous electrical voltage in the control cabinet despite the switched off main switch
  - If the machine is only switched off at its main switch, dangerous electrical voltage is nonetheless still present at several terminals in the control cabinet. In particular, these are the main supply terminal and the input terminals of the main switch.
- Refrigeration circuit is pressurised
  - Provided it is not damaged the refrigeration circuit is closed. Therefore, a hazard is not to be assumed.

#### Note:

After switching off the unit at the main switch, if you wait for 5 minutes before opening the unit risks due to rotational energy and electrical power can be reduced. In this case only the residual thermal energy must be considered.


#### 4.4. Safety devices, guards and safeguards

##### 4.4.1. High-pressure limiter

The high-pressure limiter (PZH) is a pressure switch with manual reset. The PZH limits the condensing pressure and switches off all compressors via their load contactors when the maximum permitted system operating pressure is reached. It is part of the safety chain. The PZH is installed on the refrigerant collector for the chiller types cBoxX 60 – cBoxX 120 (see Figure 9: **Position of the high-pressure limiter (PZH)**). If the PZH has been activated, a message is output at the operating terminal. In this case, please following the instructions in the Chapter Troubleshooting (see **Appendix I**).



High pressure limiter (PZH)  
cBoxX 30 – cBoxX 100



High pressure limiter (PZH)  
cBoxX 120 –

Figure 9: Position of the high-pressure limiter (PZH).

#### 4.4.2. High-pressure monitoring

If the high pressure in the refrigeration circuit of your machine increases to a maximum value, the compressors are switched off via the high-pressure limiter (see **Chapter 4.4.1 High-pressure limiter**). A manual reset is required.

The high-pressure monitoring on the other hand reduces the compressor output before the PZH's switch-off value is reached. This is done by successive switching off of one or more compressors. A message is output at the control panel. When the high pressure has reduced to a minimum value of 31.5 bar, the compressors are released once more. In most cases partial shutdown of the compressors enables operation of the chiller to be maintained with reduced output.

If the high-pressure monitor has triggered, please follow the instructions in the Chapter Troubleshooting (see **Appendix I**).

#### 4.4.3. Low-pressure monitoring

If the low-pressure in the refrigeration circuit of your system is too low for the specified cooling medium there is a risk of freezing. For this reason the low pressure is monitored continuously and if it falls below a minimum value, one or more compressors are switched off successively. A message is output at the control panel. If the low pressure has increased to a minimum value the compressors are released once more. In most cases partial shutdown of the compressors enables operation of the chiller to be maintained with reduced output.

If the low-pressure monitor has triggered, please follow the instructions in the Chapter Troubleshooting (see **Appendix I**).

#### 4.4.4. Flow monitoring

If the volumetric flow of the cold water which is pumped through the evaporator is too low, there is a risk of freezing. For this reason the flow through the evaporator is monitored continuously. If the volumetric flow rate is only around 50 % of the nominal volumetric flow rate, the message "Flow warning" appears.

If the rate falls below the minimum value of 20 % the compressors are switched off and the message "Flow stop" appears. In this case, please follow the instructions in the Chapter Troubleshooting (see **Appendix I**).

#### 4.4.5. Personal protective equipment when operating the machine

Operating the machine involves making settings at the control panel. During operation of the machine its cover panels are installed, the machine is completely enclosed. No protective equipment is needed.

We recommend ear protectors be worn by persons with jobs that require them to be continuously in the immediate vicinity of the chiller. Please refer to the sound emission information included in the technical data.

#### 4.5. Personal protective equipment for servicing work


Servicing work on the machine includes all work for which the machine is opened and one or more cover panels are dismantled. In particular, this includes cleaning work in accordance with **Chapter 9 Cleaning** and maintenance work in accordance with **Chapter 10 Service**. Before work is carried out on the chiller the protective equipment described in **Table 9: Definition of the safety symbols** must be used.

Table 10: Personal protective equipment for servicing work

	<b>Wear foot protection!</b>
	<b>Wear hand protection!</b>
	<b>Wear eye protection!</b>
	<b>Wear protective clothing!</b>

## 4.6. Airborne sound emissions

The airborne sound emissions data is given as the sound pressure level, measured at a distance of five metres without reflection. Its maximum value is shown in the technical data. This only occurs at the highest fan speed at the air intake side of the chiller (**Figure 9**, measuring point [1]). The emissions in [2] to [4] are generally around 10 % lower than [1].



**Figure 10: Airborne sound emissions**

In partial load mode or under favourable ambient conditions (see **Chapter 4.7.1 Noise**) the fan speed and therefore the sound emissions reduce automatically.

## 4.7. Notes on reducing noise and vibration

### 4.7.1. Noise

Details of your chiller's airborne sound emissions are given in **Chapter 4.6**.

To reduce noise pollution caused by airborne sound emissions it is advisable to install the chiller out of doors and out of the range of workplaces.

If this is not possible we recommend that when the unit is installed attention is paid to ensuring that the air intake side is not pointed directly at a workplace/workstation.

High ambient temperatures mean high fan speeds and this increases the noise levels produced. It is advisable not to expose the chiller to direct sunlight or to install it in rooms with high air temperature. Further information is given in **Chapter 6.2 Installation site**.



#### 4.7.2. Vibration

The chiller is designed so that the vibrations caused by the compressor are largely isolated by the chiller's frame.

To minimise the effect of vibration still further it is possible to install the chiller with optionally available levelling feet (**3.20 Levelling feet** . These are fitted with damping elastomers.

#### 4.8. Residual risks

##### 4.8.1. Electrical



If all safety provisions are complied with there is no risk.

##### 4.8.2. Mechanical



If all safety provisions are complied with there is no risk.

Mechanical damage to components or pipes of the refrigerant circuit can cause refrigerant to leak. Leaking refrigerant can cause cold burns.

##### 4.8.3. Chemical

	<b>ATTENTION! Toxic and caustic products are produced by the thermal decomposition of the R410A refrigerant.</b>
	<b>ATTENTION! Do not install in rooms with naked flames or smoke.</b>

##### 4.8.4. Other

	<b>ATTENTION! Risk of suffocation if the chiller is installed in a room that is too small. Please note and follow <i>Chapter 6.2.2</i>.</b>
	<b>ATTENTION! In the EU you must follow the provisions of EN378-3. Please also note and follow the local installation regulations and provisions, especially the Ordinance on handling water pollutant substances and BGR500 Chapter 2.35.</b>

## 4.9. Dangerous substances

### 4.9.1. Refrigerant R410A

First aid measures:

- After inhaling: remove victim to fresh air, ensuring your own safety, and keep the person at rest in a comfortable position. Get medical attention. If the person stops breathing, give artificial respiration
- Following skin contact: leave clothing that has fused with the skin. Rinse areas damaged by cold with lukewarm water (never use hot water). Do not rub! Cover with sterile dressing. Ensure medical treatment is provided.
- Following eye contact: rinse the eyes with clean water or eyewash solution for at least 15 minutes with the eyelids open. Consult an eye specialist.
- After swallowing: swallowing is not considered to be a likely risk as the refrigerant in the surroundings is gaseous.

Notes for the doctor: do not give the patient catecholamine or adrenalin ephedrine preparations.

Fire-fighting measures::

- Suitable extinguishing agents: The product itself is not flammable. Match the extinguishing measures to the surrounding fire. Cool containers with sprayed water.
- Particular hazards due to the substance, its combustion products or gases formed: forms toxic and caustic gases and fumes on decomposition.
- Special protective equipment for fire-fighting: self-contained or air-line breathing apparatus and acid-resistant protective suit for deployment in immediate vicinity.
- Further information: The effect of fire can cause bursting or explosion of the container. Ignitable gas-air mixtures possible under certain conditions.

Measures in case of accidental release::

- Environmental protection measures: where possible do not allow the product to get into the environment.
- Cleaning procedure: leave the product to evaporate.

Handling and storage:

- Handling: fire and explosion protection: heating results in increased pressure and a risk of bursting. Cool containers at risk with water. Open the containers slowly and carefully.

Personal protective equipment:

- Respiratory protection: not necessary if adequate ventilation available. Self-contained or air-line breathing apparatus within enclosed rooms, if insufficient oxygen supply available, in case of substantial or uncontrollable release. Only use breathing apparatus in accordance with the international / national standards. Only use breathing apparatus, no filtering devices.
- Hand protection: chemical-resistant protective gloves. Recommended material: Polyvinyl alcohol.
- Eye protection: close-fitting safety glasses/goggles.

General protection and hygiene measures:

- Do not inhale fumes / aerosols.
- Do not eat/drink or smoke during work.

#### 4.9.2. ÖI POE 160SZ

First aid measures:

- After inhaling: remove victim to fresh air, ensuring your own safety, and keep the person at rest in a comfortable position. Get medical attention.
- Following skin contact: remove soiled, soaked clothing. Wash skin with water. If symptoms develop, get medical advice.
- Following eye contact: rinse the eyes with clean water or eyewash solution for at least 10 minutes with the eyelids open. Consult an eye specialist.
- After swallowing: can cause vomiting. Have the mouth rinsed out with water and give the patient two glasses of water to drink. Get medical advice.
- Notes for the doctor: symptomatic treatment and assistive therapy as indicated.

Fire-fighting measures:

Low fire risk. Product only ignites in case of very large heat supply.

- Suitable extinguishing agents: match to the surroundings. Carbon dioxide, powder and foam extinguishing agents. Use water with caution to avoid possibly considerable steam generation.
- Particular hazards due to the substance, its combustion products or gases formed: irritant fumes are released during thermal decomposition.
- Special protective equipment for fire-fighting: self-contained or air-line breathing apparatus and acid-resistant protective suit for deployment in immediate vicinity.
- Further information: The effect of fire can cause bursting or explosion of the container. Ignitable gas-air mixtures possible under certain conditions.

Measures in case of accidental release:

- Environmental protection measures: do not allow the product to get into the sewers or bodies of water. Absorb with sand, soil or a similar absorbent material. Ensure proper disposal in containers.
- Cleaning procedure: Clean the contaminated area with water. Caution! Slipping hazard!
- Further information: Inform the police or competent authorities in case of penetration in the sewers or bodies of water.

Personal protective equipment:

- Respiratory protection: not necessary if adequate ventilation available. Self-contained or air-line breathing apparatus within enclosed rooms, if insufficient oxygen supply available, in case of substantial or uncontrollable release. Only use breathing apparatus in accordance with the international / national standards. Only use breathing apparatus, no filtering devices.
- Hand protection: Protective gloves. Recommended material: nitrile rubber.
- Eye protection: close-fitting safety glasses/goggles.

Handling and storage:

- Handling: avoid lengthy skin contact. Avoid inhaling high concentrations of vapour. Avoid inhaling high concentrations of fumes.
- Storage: suitable material for containers: mild steel. Tightly close unused containers to prevent the penetration of moisture. Keep away from strong oxidants.

#### **4.10. Reasonably foreseeable misuse**

Reasonably foreseeable misuse, for the users of the chiller, means foreseeable use in a way not intended according to the operating instructions. It is due to foreseeable human behaviour.

The following dangerous situations can arise due to misuse which could reasonably be expected:

- dangerous voltage of electrical components, if the machine is not disconnected from the power supply before it is opened.
- the fan and compressor can start up suddenly, without any visible change to the machine's state.
- even if the machine has been disconnected from the power supply, the surfaces of components in the unit can still be very hot or cold.
- risk of damage to external hydraulic components if the cold water feed is confused with the cold water return.
- danger caused by using media in the unit that have not been approved.
- danger caused by connecting an incorrect source of power.

#### 4.11. Information for emergencies

If an emergency occurs during operation of the chiller, the machine must be disconnected from the mains at once using the master switch. Remove people from the danger zone immediately. An emergency situation can among other things be:

- a leak and escape of refrigerant and/ or oil.
- a part of the machine becoming mechanically detached from it.
- the machine making unusual noises.
- the machine vibrating severely.

Then contact the KKT chillers Service Team. If you detect a refrigerant or oil leak, proceed as described in Chapter 4.9 Dangerous substances.

### 5. Handling and storage


The chiller is fixed on a wooden pallet in the factory for delivery. The machine is additionally protected against damage by polystyrene corner protectors and stretch film. Therefore you should remove the packaging as late as possible.

#### 5.1. Dangerous goods

Chillers with refrigerant capacity >12 kg must be declared as dangerous goods in accordance with UN2857. The cBoxX 30 – cBoxX 70 chillers have been specified so that they contain <12 kg refrigerant. This reduces the logistics costs of our customers and final consumers.

#### 5.2. Transport

The chiller may only be transported using a fork lift truck or crane with sufficient rated capacity. The net weight of your machine is given in the technical data. Please note that if a machine has already been in operation, it can contain residual fluids, which increase the transport weight.

	<b>ATTENTION! The chiller must not be tilted by more than 10° from the perpendicular position.</b>
---	--

### 5.2.1. Forklift truck

It is possible to transport the machine both in a packed and an unpacked condition by means of forklift truck. Please note that the centre of gravity may vary depending on the model.





Figure 5: C6845-0 center of gravity cBoxX 30 - 60





Figure 6: C6846-0 center of gravity cBoxX 70 - 100






Figure 13: C6846-0 center of gravity cBoxX 120







### 5.3. Unpacking

	<p><b>ATTENTION! Packing straps are mechanically stressed and can snap back when cut. Risk of injuries!</b></p>
---	---

Remove all straps, films, corner protectors and spacers carefully. Optional accessories may be located under the film. Ensure that they are not damaged.

The packaging can be recycled according to the local regulations. Refer to the following table for details of the packaging materials used:

**Table 11: Material of packaging**

Element	Material	Recycling code
Polystyrene corner protectors	Polystyrene	
Stretch film	Polyethylene	
Edge protection / corner protectors	Cardboard	
Packaging tape	Polypropylene	
Strapping seals	Steel, galvanized	
Wooden pallet	Untreated raw wood, spruce or pine without bark	

### 5.4. Storage

If the chiller is stored for more than one month, it should remain in the transport packaging or be repacked.

The following conditions must be noted for storage:

- Avoid direct sunlight and moisture
- Ambient temperatures 30 °C to 50 °C

To avoid frost damage the cold water circuit must be completely drained before the chiller is placed in storage and then flushed with a mixture of water and anti-freeze (see **11.1 Draining**).

## 6. Installation

### 6.1. Overview

Several tasks are necessary to install the chiller. The following work schedule shows the order in which they are carried out:

- Prepare the installation site
- Install the machine
- Flush the cold water circuit
- Hydraulic installation
- Fill the whole system
- Vent the whole system
- Electrical installation

### 6.2. Installation site

#### 6.2.1. General information

The chiller is suitable for both indoor and outdoor installation (note options packages). The electrical degree of protection corresponds to IP54. If installed indoors, ensure sufficient air exchange. An enclosed room will steadily heat up and the machine can switch off due to a lack of cooling. The exhaust heat from the machine can be approximately calculated as  $1.3 \times$  net refrigeration capacity. The air flow rate required for your machine is given in **Table 3 Technical data**. When choosing the installation site, ensure that waste heat from other processes cannot be guided directly onto the air intake side of the chiller.



**ATTENTION! Do not install in rooms with naked flames or smoke.**

#### 6.2.2. Minimum room volume

The refrigerant R410A contained in the system is classified in safety group A1 in accordance with EN 378-1 Table E.2. I.e. the refrigerant is not flammable and has low toxicity. If the chiller is installed in enclosed rooms without additional safety measures a minimum room volume is required. This is due to the maximum concentration occurring in an area occupied by persons in the event of release and depends on the refrigerant quantity in the chiller. Please refer to the following table for the value to be complied with for your machine.



**Table 12: Minimum volume of the installation room with regard to maximum refrigerant concentration in case of a leakage if installed indoors**

cBoxX chiller	60	70	80	100	120
Minimum volume of the installation room (in m <sup>3</sup> )	16	20	20	20	40

### 6.2.3. Ambient temperature

The chiller is cooled by the ambient air and the lower the temperature of this cooling air the more economically the chiller works. Direct sunshine or exhaust air from other machines heats up the surrounding air and must be taken into account when installing the chiller. Preference is for a shaded installation. The maximum ambient temperature is given in the technical data.

### 6.2.4. Effect of surrounding air flow

The chiller emits heat to the surrounding area, the machine also draws in cooling air. The machine controls the quantity of cooling air automatically via the speed of the fan. Air currents surrounding the machine, such as the wind, can affect this control and endanger operation of the machine. If a constant direction of an air current is known at the installation site, this should not be directed at the air intake side of the chiller.

### 6.2.5. Minimum clearances

The minimum clearances around the machine are made up of service clearances and clearances to ensure optimum air supply. On the one hand accessibility must be ensured from all sides, in addition, an unhindered, sufficient quantity of cooling air must be able to be drawn in and blown out upwards. If the minimum clearances are not complied with there is a risk of an air short-circuit between the air intake and discharge side. As regards to the minimum clearances please refer to **Appendix III**.

### 6.2.6. Surface and foundation

The surface on which the machine is installed must be flat and horizontal. All the machine's feet must have uniform contact with the ground. Ensure that the ground/subsoil has sufficient load bearing capacity. According to the installation instructions (**Appendix III**) a continuous concrete foundation with the given minimum size is recommended. For details, the gross weight of your machine is listed in the technical data (**Table 3: Technical data**). In the case of chillers equipped with a tank the net weight increases during operation by the quantity of liquid in the tank. This gives the gross weight.

If it is not possible to lay a foundation, the machine can also be positioned on a baseframe made of steel sections. Please also ensure here that all the unit feet have uniform contact with the baseframe.

### 6.2.7. Stability

The normal situation is for the machine and the baseplate to be stood firmly on the ground. It is not necessary to anchor the machine to the ground. However, if this is necessary due to the surrounding conditions, the machine can be equipped with the optionally available levelling feet (**3.20 Levelling feet**). The levelling feet provide very good resistance to slipping. If this is not sufficient for your application the machine can also be bolted to the ground. Holes are provided in the machine baseplate for precisely this purpose. These are shown in **Appendix III**. The system designer is responsible for choosing suitable fixing elements.



### 6.2.8. Levelling

If it is necessary to level the chiller on the ground or floor, this can be done using the optionally available levelling feet.

### 6.2.9. Vibration isolation


If it is necessary to isolate the chiller on the ground or floor, this can be done using the optionally available levelling feet. The levelling feet are fitted with vibration-isolating elastomers.

### 6.2.10. Installation

	<p>Unit outlet cold water circuit 1 (supply line)</p>
	<p>Unit outlet cold water circuit 1 (return line)</p>

### 6.2.11. Hydraulic installation

The system designer is responsible for choosing the material and the cross-section of the hydraulic connections between the chiller and the application. Other dependent factors include the accepted pressure loss in the connection lines and the available pump pressure. When designing the connections attention must also be paid to the minimum flow rate to be maintained and sufficient resistance to the maximum pump pressure.

	<b>ATTENTION! Galvanised pipes must not be used if water-glycol mixtures are used! Formation of decomposition products, which result in silting up of the system!</b>
---	---

### 6.2.12. Frost protection measures

The chiller is exposed to the risk of frost in two different situations. Both with an ambient temperature  $< 0\text{ }^{\circ}\text{C}$  and a feed temperature  $< 8\text{ }^{\circ}\text{C}$  there is a risk of freezing of parts of the cold water circuit system.

Installation in ambient temperature  $< 0\text{ }^{\circ}\text{C}$  with anti-freeze

The machine is protected against freezing by anti-freeze. Ensure that you always comply with the requirements with regard to the operating fluid and the mix ratio.

Feed temperature  $< 8\text{ }^{\circ}\text{C}$

The machine must be protected against freezing by anti-freeze in accordance with the specifications. Please note that the evaporation temperature is always significantly below the cold water feed temperature. Even within the supposedly safe temperature range there can still be a risk of freezing. Ensure that you comply with the requirements with regard to the operating fluid and the mix ratio.


### 6.2.13. Flushing the cold water circuit

Contamination of external pipes and components can damage the chiller. Before the chiller is connected hydraulically with the cold water circuit this must be flushed several times. If there are dirt traps in the cold water circuit they must be cleaned after the flushing.

### 6.2.14. Filling


Once the hydraulic installation of the overall system has been completed, the chiller can be filled. All shut-off valves in the cold water circuit must be opened.

In the standard version the machine does not have a filling connection. To fill the system, provide a filling connection in the process circuit. If an external tank is installed in the process circuit, fill your system directly in this tank.

	<p><b>ATTENTION! Only use approved refrigerants see Chapter 2.15! If there is a risk of frost, note Chapter 6.2.14!</b></p> <p><b>All operating liquids must be mixed before they are added to the system!</b></p>
---	--

### 6.2.15. Venting

If your chiller contains a horizontal pump, the pump does not have to be vented. Before switching on the pump the vent plug must be opened at the automatic vent and left open while the unit is running until all air has completely escaped from the pump body (see *Figure 15*).

	<p><b>ATTENTION! Please also note and follow the local installation regulations and provisions, especially the Ordinance on handling water pollutant substances and BGR500 Chapter 2.35.</b></p>
---	--

We recommend also installing an automatic venting valve at the highest point in the cold water circuit.






Figure 7: Automatic vent valve

### 6.2.16. Electrical installation

	<b>ATTENTION!</b> The electrical installation, testing and commissioning may only be carried out by qualified personnel. Note and follow the local regulations.
	<b>ATTENTION!</b> Do not switch on the chiller until the hydraulic installation is completed and the machine has been filled as specified in Chapter 6.2.15. Otherwise the machine could be damaged.

The chiller is connected electrically to its main supply terminal in the control cabinet. (see *Figure 16 Main supply*). A corresponding circuit diagram is included with the unit.




Figure 8: Main supply (here: cBoxX 60 – cBoxX 100)

The dimensioning of the load cable and the fusing must be in accordance with the machine's technical data and the local regulations of the power supply company.

The supply cable must be routed into the machine. Cut-outs are provided for this purpose in the baseplate and in the compressor mount (cBoxX 60 – cBoxX 100). Feed the supply cable, protected by rubber grommets, through these openings (see *Figure 16 Main supply*).

Never switch on the chiller immediately if the machine is moved from a cold into a warm room. The condensing moisture can damage electronic components. For the initial startup or following a lengthy period out of use all the electronic components must have become acclimatised.

Use an external control cable to set the chiller's release (see *Chapter 8.3 External release*) this cable is laid parallel with the supply cable and is wired at the corresponding terminals in the control cabinet. The machine is bridged at the corresponding terminals on delivery.

Once the electrical installation has been completed the phase sequence must be tested. This is done by checking the rotational direction of the pump. This has a rotational direction arrow on it. If the rotational direction does not match the arrow, the phase sequence can be corrected by swapping two phases at the main supply.

## 7. Commissioning

Before commissioning the chiller the checklist must be used to check whether all the necessary work in Chapter 6 *Installation* has been carried out properly.

The chiller must be installed for at least 12 hours at  $>+5$  °C, so that the compressor oil can heat up and the refrigerant can be liberated from the oil.

If your machine is equipped with oil sump heating and the machine has been completely installed, it is permissible to switch on the machine at the main switch and to allow the compressor to be preheated for at least 3 hours without enabling the cooling.

### 7.1. Installation checklist

- Unit installed horizontal and stable?
- Any vibration damping and floor anchors installed?
- Spaces / clearances around the unit are adequate according to the requirements?
- Air intake side free from packaging materials, etc.?
- Hydraulic connection OK?
- Cold water circuit filled in accordance with the specifications? Water quality OK?
- Whole system flushed? Dirt trap cleaned?
- Cross-sections adequately dimensioned?
- Electrical connection OK? Electrical power is available?
- External pumps OK? Rotational direction?
- Unit cover closed?
- Overall system OK and ready for commissioning/startup?
- Compressor "preheated"?
- External release OK?

After checking the above list you can continue with Chapter 8 *Operation* .

## 8. Operation

The chiller is designed for fully automatic operation.

### 8.1. Switching on

First, switch on the machine at the main switch (component 5 in *Illustration 19: C6842 Display and operating modes*). A start screen appears on the display.

### 8.2. Selecting the operating mode

In the Start screen you can choose between the following three operating modes:

- **STANDBY**  
When selecting the "STANDBY" mode, all electrical components, except the compressor heater and controller are off.

This operating mode is to be selected if the chiller was disconnected from the power supply in ambient temperatures  $<5^{\circ}\text{C}$  for longer than 6 h. In this case the compressors must be preheated for 3 h, so that the refrigerant can escape from the oil.

- **AUTO**  
With the selection of "AUTO" operating mode the machine is ready for use. The fully automatic operation only starts in this mode if the external release has been installed beforehand as described in Chapter **8.3 External release**.
- **ON**  
Fully automatic operation (without external release) starts with the selection of "ON" mode.

### 8.3. External release

In the delivered state the contact for the external release is bridged. An external control cable can be wired up in place of the bridge. Please refer to Chapter **6.2.18 Electrical installation** for information on the external release. Fully automatic operation starts with this external release.

## 8.4. Control

The chiller's control consists of a control board and a control panel, which communicate with each other via a BUS connection.

The control board operates autonomously so that if the control panel or communication fails, operation continues to be possible if no other fault prevents operation.

The program, target / setpoint values, parameters and times are stored in an Eprom in the control and are therefore retained even in the event of a power failure. Therefore the control does not require a buffer battery.

## 8.5. Control panel

The following **Figure 17** shows the chiller's display elements and controls.




Figure 17: C6842 Display and operating modes

Table 13: Description for C6842

Number	Function
1	"UP" button
2	"OK" button
3	"DOWN" button
4	Display with plain text
5	Main switch



Use the "UP" and "DOWN" buttons to select the required menu item. The selected menu item is displayed with inverse text. Press the "OK" button to return to or exit the selected menu. The data is accepted at the end of the menu by selecting the box with the tick/checkmark. In the Start screen the "right" arrow points towards the Main menu. The "left" arrow indicates return to the previous menu.

The displays are divided into the two access levels

- Customer
- Factory

. Detection occurs by means of a USB stick or day password. Only the information that exists or is selected in the configuration is displayed.

### 8.5.1. Start screen




Figure 9: Start screen without alarm




Figure 10: Start screen with alarm

The general operating state of the chiller is displayed on the Start screen:

- Active alarm
- Top left-hand side: Number of pumps running
- Left-hand middle: Number of compressors running
- Bottom left-hand side: Number of fans running
- Middle: Actual value of the cold water feed
- If an alarm is active the alarm symbol is displayed

Press OK, DOWN and UP to switch to the selection fields, in which the Time - Date setting, the menu access arrow as well as the operating mode selection are located. There are three switching commands:

- STANDBY: the chiller is always switched off
- AUTO: the chiller is switched on and off via the floating contact.
- ON: the chiller is always switched on

### 8.5.2. Main menu




Figure 20: Main menu

From the Main menu you can move into the submenus or return to the Start screen.

### 8.5.3. Information

In the Information menu you can move into various submenus to obtain an overview of the state of the chiller.




Figure 21: Information

In the Measured Value (Readings) menu you can call up the values of the analogue inputs.




Figure 22: Measured Value menu

In the Status menu the states of the digital inputs and outputs and several internal control states can be called up.

<b>Status</b>		
↑	DI Reset- Taster	Aus
↓	DI Fernansteuerung	Ein
↔	DI MSS Pumpe 1	Aus
↔	DI Strömung Pumpe 1	Ein
←	DI MSS Pumpe 2	Aus
←	DI Strömung Pumpe 2	Ein

Figure 11: Status menu

The alarms are listed in the alarm menu. A detailed description is given in Chapter **8.5.5 Alarm menu**.

The operating hours counter gives information on the operating hours of the individual components. It cannot be reset.

<b>Betriebsstunden</b>		
↑	DO Pumpe 1	0 h
↓	DO Pumpe 2	0 h
↔	DO Verdichter 1	0 h
↔	DO Verdichter 2	0 h
←	DO Verdichter 3	0 h
←	DO Verdichter 4	0 h

Figure 12: Operating hours counter

The digital inputs show the state at the terminals of the digital inputs.

<b>Digitale Eingänge</b>		
↑	DI1 Klemme 1,2	Ein
↓	DI1 Klemme 3,4	Aus
↔	DI1 Klemme 5,6	Ein
↔	DI1 Klemme 7,8	Ein
←	DI1 Klemme 9,10	Ein
←	DI2 Klemme 1,2	Ein

Figure 13: Digital inputs

The digital outputs show the state of the output relays.

<b>Digitale Ausgänge</b>		
↑	DO1 Klemme 1,2	Ein
↓	DO1 Klemme 3,4	Ein
↔	DO1 Klemme 5,6	Ein
↔	DO1 Klemme 7,8	Ein
←	DO2 Klemme 1,2	Aus
←	DO3 Klemme 1,2	Aus

Figure 14: Digital outputs

The analogue inputs show the signal upstream of the analogue digital converter. The value must be between 0 and 4095. 0 means that no sensor is connected. 4095 means that the input is short-circuited.

<b>Analoge Eingänge</b>		
↑	AI1 Klemme 1,2	3147
↑	AI2 Klemme 1,2	1937
↑	AI2 Klemme 3,4	2232
↑	AI2 Klemme 5,6	1884
←	AI3 Klemme 1,2	2969
←	AI3 Klemme 3,4	2569

Figure 15: Analogue inputs

The analogue outputs show the signal upstream of the digital-analogue converter. The value 10000 corresponds to an output voltage of 10 volts.

<b>Analoge Ausgänge</b>		
↑	A01 Klemme 1,2	0
↑	A01 Klemme 3,4	0
↑	A01 Klemme 5,6	5800
↑	A01 Klemme 7,8	0
←	A02 Klemme 1,2	7000
←	A0 Klemme 3,4	8000

Figure 16: Analogue outputs

#### 8.5.4. Settings

All setpoint/target and parameter values and times are stored in the Settings menu.

<b>Einstellung</b>	
	Grenzwertüberwachung
	Regelung
	Pumpensteuerung
	Kompressorsteuerung
←	Anlagenkonfiguration

Figure 17: Setting

### 8.5.5. Alarm menu

The alarm is acknowledged if the "OK" button is pressed for longer than **eight** seconds.  
(after five seconds the display switches back to the main menu)

Alarm messages can have three states:

- active: The alarm is still active. (e.g. DI MSS ...) The motor protection switch has triggered.
- SH: The alarm is no longer queued. E.g. the motor protection switch has been unlocked on the hardware side but has not yet been acknowledged at the control panel.

Alarms that have the preceding code DI refer directly to the digital input. All digital inputs must be closed in a fault-free state. The code AI indicates a sensor error of an analogue input. The analogue input must be checked for interruption and short circuit. Alarms without abbreviations are formed internally in the control.




Figure 30: Alarm menu

### 8.6. Parameters

The parameters are divided into the three display and access levels:

- Customer, user
- Factory setting

A parameter can have a lower display level than access level. I.e. not all the parameters displayed can be changed.

The specific parameter list for your application is enclosed with the unit.

## 8.7. Controller description

### 8.7.1. Switching the chiller on/off

The following conditions must be fulfilled for the chiller Standby state:

- The control has finished its initialisation routine
- Release of at least one primary pump,
- Release of at least one condenser fan,
- Release of the cold water feed or return sensor,
- No exceeding of the cold water feed temperature,
- Release through tank level monitoring,
- Release through cold water pressure monitoring at the evaporator inlet.

A primary pump is released if:

- It is selected in the system configuration of the software,
- No motor protection switch faults are queued,
- No flow monitoring faults are queued,
- No minimum or maximum pump pressure faults are queued.

A condenser fan is released if:

- No motor protection switch faults are queued,
- No fault is queued at the digital fault input (e.g. control unit group fault).

From the Standby state, a software switch in the display can be used to switch the chiller between Auto-On or Manual-On. In Automatic mode the floating contact for the remote control must be closed.

When the system is switched on the primary pumps are switched on with a 3.5 s delay. After a further 3.5 s the fan control is released.

When the primary pump is switched on a timing element starts for each pump, which activates the monitoring of the minimum and maximum cold water pressure at the pump outlet. When the pump is switched on a timing element also starts for release of the compressor's temperature control. The compressor's temperature control is released when the time of a pump has expired. This time is also used for activation of the flow monitoring.

The pressure and flow monitoring takes place with two timing elements:

- Delay at start; the pressure or the flow monitoring does not trigger an alarm.
- Delay during operation; in order to ignore short-term fluctuations in pressure or flow, the alarm is delayed.

When the system is switched off the temperature control is locked immediately and therefore the compressor is switched off. The pump continues to run to prevent uncontrolled continued evaporation.

### 8.7.2. Cold water feed temperature control

In the normal case the sensor in the tank (system with tank, with pump) is used to control the cold water feed temperature. If this sensor fails, the control switches internally to the sensor in the cold water return and the setpoint value is increased by a defined value.

A purely proportional controller is used, which generates an output signal from -100 % to + 100 %. The switching on and switching off points of the cooling levels are set within this range. If the setpoint is changed, the switching ratio between the compressors is retained, it is shifted overall. If the proportional range is changed the switching ratio is also retained. The range is extended or reduced.




Figure 18: Cooling and heating sequence

Different operating states reduce the number of cooling levels required by one cooling level:

- High pressure warning
- Low pressure warning
- Difference between high and low pressure is too large.



### **8.7.3. Compressor control**

The control is defined for a refrigeration circuit with a maximum of four compressors. The number of compressors is selected by means of coding resistance. The number of compressors is determined once when the control is restarted (switching on of the operating voltage) and is compared with the number of the last restart. If these are not the same the "Coding resistance changed" alarm is generated. When the alarm is acknowledged the new number of compressors is stored in the E-EPROM and the factory setting is accepted as the new number of compressors.

The compressors are requested depending on the controller output signal. The compressor with the least number of operating hours switches on first. If no more refrigerating capacity is required the compressor that switched on first also switches off first. The compressors are switched on with a time delay (comment: only applies if several compressors exist)

In the event of a fault in a compressor (motor protection switch) a fault changeover is activated. The high pressure is monitored on the hardware side by means of the high-pressure limiter. If it is triggered all compressors switch off immediately. In addition, the high pressure is controlled by means of a pressure transmitter. This also switches off the compressors if the setpoint value is exceeded, but releases them again if the value falls below the release value. Before switching off the, high-pressure transmitter signals a warning.

Low pressure is also monitored by pressure transmitters. If the value falls below the setpoint value the compressors switch off. If the switch-off value is exceeded by the hysteresis, the compressors are released again. The triggering of the alarm is delayed by two timing elements. The first timing element is started with the request for the compressor. If no intake pressure has built up by the time the time expires, the low-pressure fault alarm is triggered. After the start time has expired the low pressure may exceed the switch-off value for a short time. If this occurs more than three times within an hour the compressors are blocked. Before a low-pressure fault is triggered, a low-pressure warning is signalled.

### **8.7.4. Fan speed control**

Due to the continuous adjustment in the number of fans, the condensing pressure is kept constant depending on the ambient temperature by means of a PI controller. As the condensing pressure at the moment in which the compressor is switched on rises very fast, the PI controller is superimposed by a P controller with limiting setpoint. This only intervenes if the PI controller is too slow.

### **8.7.5. Electronic expansion valve control**

An electronic expansion valve with PI controller is used to keep the overheating constant. To prevent the maximum operating pressure (MOP) from being exceeded, a P controller is used, which counteracts when the MOP is approached and limits opening of the electronic expansion valve.

### **8.7.6. Temperature limit monitoring**

The temperature of the cold water feed is monitored for a minimum and maximum limit value if the chiller is switched on (pump is running). If the limit value is exceeded or the minimum is not reached, an alarm is triggered with time delay, which switches off the chiller.

### 8.7.7. Group fault alarm

A group fault alarm is triggered if an alarm occurs. All alarms are included in the group fault, but not the warnings. The group fault signalling relay has a floating changeover contact and is energised in fault-free operation, in order to ensure wire break monitoring.

## 8.8. Operating modes

It is possible to choose between two operating modes:

### 8.8.1. ECO mode

The default setting of the Compact-Line provides for operation in ECO mode ("Run" parameter is set to "0"). As a result, the increase in fan speed reduces the condensing pressure to the minimum necessary value in the respective operating point – the electrical power consumption of the overall system is limited to a minimum.

### 8.8.2. Comfort mode

In case of strict sound emission requirements, the fan speed can be reduced to the minimum necessary value in the respective operating point and sound power level limited to a minimum. To do this, the "Run" parameter must be set to "1". As a result of the lower air flow rate a reduced output of around 3% is to be expected.

The optimised parameter list for your application is enclosed with the unit.

## 9. Cleaning

### 9.1. Air filter mat

To maintain high performance, the optional air filter mat (**3.19 Air filter mat**) must be checked for contamination at least once a month. The appropriate air filter mats can be ordered at any time as an original spare part – please contact our KKT chillers Service Team (**Contact details**).

### 9.2. Condenser

To maintain high performance, the microchannel heat exchanger must be cleaned if there is any visible contamination, but at least annually. To do this, disconnect the unit from the power supply and remove the service panels and the condenser protective grille (panels 3 and 5, see Chapter **1.2 Elements**). First of all, remove coarse dirt particles from the outside using a standard vacuum cleaner. Then flush the microchannel heat exchanger carefully, in the opposite direction to the air flow, from inside with warm tap water. Then clean with a wet vacuum cleaner until the surface is dry again. For versions with water-cooled condensers see complete cleaning of the cold water circuit.

### 9.3. Water filter

To ensure the required water quality and the required water circulation quantity, the optional water filter (**3.22 Filter assembly** group coolant circuit) must be checked for contamination at least once

a month. The appropriate filter unit can be ordered at any time as an original spare part – please contact our KKT chillers Service Team (**Contact details**).

#### **9.4. Complete cleaning of the cold water circuit**

Due to the complexity and diversity of the possible external materials, we recommend that the complete cleaning of the cold water circuit only be carried out by qualified personnel – please contact our KKT chillers Service Team (**Contact details**).

### **10. Service**

All service work may only be carried out by properly trained, competent personnel.

#### **10.1. Maintenance**

Reliable operation and a long service life for the entire system can be guaranteed by proper maintenance.

The purpose of the maintenance is:

- to ensure that the machine operates reliably and without unexpected failures
- to plan further service work in order to minimise downtimes

An overview of the maintenance intervals as recommended by the VDMA is given in **Appendix II**. In addition, the national regulations of the respective installation site must be followed.

Please note that the points listed represent the minimum maintenance required. By increased monitoring, system reliability can be enhanced. Please contact our service department at any time about maintenance quotations / service agreements or online at ([www.kkt-chillers.com/service/wartung](http://www.kkt-chillers.com/service/wartung))

#### **10.2. Disposal**

Troubleshooting and fault correction instructions are given in **Appendix I**.

Our technical customer service can be reached around the clock and will assist you with all service matters (maintenance, repairs, spare parts, etc.):

Service Team Europe  
T +49 9228 9977 7190  
E [service@kkt-chillers.com](mailto:service@kkt-chillers.com)  
W [www.kkt-chillers.com](http://www.kkt-chillers.com)

Service Team USA  
TF +1 866 517 6867  
E [techsupport@kkt-chillersusa.com](mailto:techsupport@kkt-chillersusa.com)  
W [www.kkt-chillers.com](http://www.kkt-chillers.com)




Service Team East Asia  
S +86 512 6790 3091  
E [service@kkt-chillerscn.com](mailto:service@kkt-chillerscn.com)  
W [www.kkt-chillers.com](http://www.kkt-chillers.com)

### 10.3. Spare parts

To ensure that the performance of your chiller is not impaired, we recommend that you only use original spare parts from KKT chillers. By doing so, you ensure the reliability and quality of the machine. Should you have any questions about spare parts, please contact our KKT chillers Service Team (**Contact details**) or online at ([www.kkt-chillers.com/service/spare-parts](http://www.kkt-chillers.com/service/spare-parts))

## 11. Decommissioning/Taking out of service

	<p><b>ATTENTION! Decommissioning must only be carried out by professional and qualified technicians.</b></p> <p><b>They must also be familiar with the local regulations.</b></p>
---	---


For safety-relevant instructions regarding possible residual energy, please refer to **Chapter 4.3 Residual energy**.

### 11.1. Draining

If the system is filled and there is a risk of frost, suitable measures must be taken to protect the liquid from frost. The complete cold water circuit must be fully drained before any lengthy stoppage of the unit. Do this as follows:

1. Drain the tank via the drain cock provided
2. Drain the pump using the drain plug provided

The position of the drain plug is shown in *Figure 32*.



Drain plug  
(Allen key 10 mm)

**Figure 19: Position of the pump drainage (here: horizontal type)**

To prevent frost damage the cold water circuit must then be flushed with a mixture of water and 40 % by vol Antifrogen-N (or equivalent).

### 12. Recycling

	<p><b>ATTENTION! Dismantling must be carried out by professional and qualified technicians.</b></p> <p><b>Water and refrigerant pipes are pressurised!</b></p> <p><b>They must also be familiar with the local regulations.</b></p>
--	---

All parts (e.g. refrigerant, oil, glycol, metal, electronics, battery etc.) must be recycled, reused or disposed of. Please note and follow all local and national regulations and if necessary contact your local waste management agency.

A specialised disposal company must be contracted to dispose of these wastes. They issue a proof of disposal which must be archived. The chiller can be returned to KKT chillers for disposal. Please contact our KKT chillers Service Team for details (*Contact details*).


### 13. Products, solutions and services


Apart from the Compact-Line, KKT chillers also offers other products, solutions and services which are not described in this document. For more information, visit our homepage at <http://www.kkt-chillers.com> or get in touch with your KKT chillers contact – we look forward to hearing from you!

#### List of tables


Table 1: Contact details .....	2
Table 2: Safety instructions .....	7
Table 3: Technical data.....	8
Table 4: Explanation of terms.....	14
Table 5: Materials used in the standard version.....	18
Table 6: Water quality .....	19
Table 7: Mixing ratios AFN and AFL (or comparable) .....	20
Table 8: Definition of the safety symbols.....	26
Table 9: Hazard warnings .....	27
Table 10: Personal protective equipment for servicing work .....	31
Table 11: Material of packaging.....	39
Table 12: Minimum volume of the installation room with regard to maximum refrigerant concentration in case of a leakage if installed indoors .....	41
Table 13: Description for C6842.....	48


## I. Menu navigation


















<b>Analogue inputs</b>	
A01 clip 1,2	Inc
A01 clip 3,4	Inc
A01 clip 5,6	Inc
A01 clip 7,8	Inc
A02 clip 1,2	Inc
A02 clip 3,4	Inc
AIO1 clip 3,4	Inc
AIO2 clip 3,4	Inc











**Control compressor**


Time between 2 starts	300	sec.
Min timeout	5	sec.
<b>Low pressure (LP)</b>		
LP warning(STOP+dP)	0.2	bar
Time delay	30	sec.
LP STOP	7.3	bar
Time delay start	60	sec.
Time delay running	3	sec.
LP ON (STOP+dP)	2.0	bar
Errors per hour	3	
Time delay	10	sec.
<b>High pressure (HP)</b>		
HP warning ON	42.5	bar
HP warning OFF	40.0	bar
Time delay	10	sec.
HP STOP	43.0	bar
HP off	40.0	bar
Time delay	10	sec.











## II. Troubleshooting

Error code	Display view	Type of message	Message description	Cause of the message	Troubleshooting	Reaction of the chiller
111	HP warning	Group warning	Condensation pressure has exceeded the warning limit	Condensation pressure threatens to run against the design limit of the high pressure stop,	Clean the condenser and filter. Check the function of the fan. Check the cooling water circuit. Install the cover panels.	All components continue to run. (Warning - this is time-delayed from V. 2.60) Alarm is saved, manual reset. Attention: Reduction of the cooling level with a separate menu item without a message.
121	LP warning	Group warning	Evaporation pressure has fallen below the warning limit	Evaporating pressure approaches the low pressure stop limit, a compressor is switched off. (If the compressor count is greater than ONE)	Check liquid flow. Check the function of the expansion valve. Check the refrigerant level.	A compressor is switched off (from V. 2.60 time-delayed) and switches on again after pressure increase. All other components continue to run. Warning is not saved, automatischer reset .
131	Superheating	Collective warning message from Version 2.71 previously fault message AL171				
151	HP STOP	Group fault alarm	Condensation pressure is outside the allowable range.	Waste heat from the chiller circuit cannot be dissipated.	Clean the condenser and filter. Check the function of the fan. Check the cooling water circuit. Install the cover panels.	All compressors shut down. (time-delayed from V. 2.60) All other components continue to run. Alarm is saved. Manual reset.

161	LP STOP	Group fault alarm	Pressure has fallen below the minimum allowable pressure on the intake side of the compressor (low pressure side).	Liquid flow through the evaporator is too low. Refrigerant loss. Faulty function of the expansion valve. Faulty function of the LP sensor.	Check liquid flow. Check the function of the expansion valve. Check the refrigerant level.	After starting the compressor, the low pressure is bridged. Then all compressors switch off. When the pressure increases, the compressors switch on again. During operation, all compressors switch off with a time delay. They switch on again when the pressure increases. The compressors restart up to 3 times, after which alarm AL162 is triggered. All other components continue to run. Alarm is saved. Manual reset.
162	LP STOP 3x	Group fault alarm	The minimum permissible pressure on the suction side of the compressor (low pressure side) was 3 times lower.	S.h. LP STOP	S.h. LP STOP	Compressor no longer starts automatically after the 3rd low pressure STOP AL161, All other components continue to run. Alarm is saved. Manual reset.
171	Superheating	Collective fault message from Version 2.70 then warning WA131	The superheat design limit has been exceeded or not reached. vBoxX Min; cBoxX Min and Max.	Superheat too low or too high		only display if alarm occurred 3 times, Alarm is saved, 2x automatic reset, then manual reset.
301	Outlettemp. max warning	Group warning	The outlet temperature of the chiller circuit is approaching the upper design limit.	Thermal overload, No refrigeration.	Check refrigerating capacity, check the function of the refrigeration circuit	All components continue to run, Warning is saved, Manual reset.
312	Min tank level warning	Group warning	Level in the tank is approaching the minimum design limit.	Level in the tank is too low, level sensor in the tank is defective.	Fill tank, Check the function of the tank sensor in the tank	All components continue to run, Alarm is saved, Manual reset.

313	EV refill time limit	Group fault alarm	The solenoid valve of the tank refill does not close within the specified time.	The freshwater supply is interrupted.	Check the function of the solenoid valve tank refill. Open the shut-off devices integrated in the supply line. Check the supply line for leakage.	Solenoid valve for tank refill closes. All other components continue to run, Alarm is saved, Manual reset.
321	Coldwater press warning	Group warning	The liquid pressure at the evaporator is approaching the minimum or maximum limit	External slide is closed, Filter soiled, Air in the system.	Open external slide, Clean filter, Vent the system.	All components continue to run, Alarm is saved, Manual reset.
325	Measuring	Group warning	Pump intake pressure is below the set setpoint	Diaphragm expansion vessel defective Quantity of water in the closed pipe system is too low	Top-up water	All components continue to run, Alarm is saved, Manual reset.
326 327	Press pump 1 min warning Press pump 2 min warning	Group warning	The pump's pressure is approaching the minimum limit	Flow rate too high, chiller resistance too low, Air in the system	Reduce flow rate, increase chiller resistance, vent the system	All components continue to run, Alarm is saved, Manual reset.
331 333	Conduc. max. STOP Conduc. max. alarm	Group fault alarm	Conductivity exceeds maximum design limit.	Conductivity too high.	Check limit design value: If available: Check DI cartridge, Check flow through DI cartridge.	All components continue to run, Alarm is saved, Manual reset.
332	Conductivitymaxwarn.	Group warning	Conductivity is approaching maximum design limit.	Conductivity too high.	Check the limit default. If installed: Check DI cartridge, Check flow through DI cartridge.	All components continue to run, Alarm is saved, Manual reset.
333	EV demin. time limit	Group warning	The demineralization solenoid valve does not close within the specified time period.	DI cartridge worn. No flow through DI cartridge. Switch-off point set too high.	Replace DI cartridge. Check flow through the DI cartridge. DI cartridge worn.	Demineralization solenoid valve closes. All other components continue to run, Alarm is saved, Manual reset.

351	Outlettemp. max STOP	Group fault alarm	Maximum outlet temperature exceeded.	No refrigeration, Thermal overload.	Check function of the chiller circuit, Check installed heat load.	Chiller switches off immediately. Alarm is saved. Manual reset.
352	Outlettemp. min STOP	Group fault alarm	Outlet temperature is below the minimum.	Check function of the tank heater, check setpoint setting, ambient temperature too low.	Check tank heater function, check setpoint, increase ambient temperature.	Chiller switches off immediately, (Until V 2.60) (Compressors switch off immediately). Pumps deactivate via follow-up time, this would be correct) Alarm is saved, Manual reset.
361	Min tank level STOP	Group fault alarm	Level in tank is below the minimum.	Level in the tank is too low, Level sensor soiled or defective	Fill tank, Check the function of the tank sensor.	Chiller switches off immediately. Alarm is saved. Manual reset.
371	Coldwater press STOP	Group fault alarm	Cold water pressure at the evaporator is too low.	External slide is closed, Filter soiled, Air in the system.	Open external slide, Clean filter, Vent the system.	Compressors switch off immediately. Pump 1 & 2 consumer pump Pumps continue to run. Pump 1 = Consumer pump Pump 2 = Evaporator pump Pump 1 continues to run. Pump 2 switches off. Pump 1 = Consumer pump Pump 2 = Redundant The required pump continues to run. Alarm is saved. Manual reset.
378	Pr.exp.vess.max Stop	no message	Intake pressure of the pump is above the set setpoint	Diaphragm expansion vessel defective Quantity of water in the closed pipe system is too high	Exchange diaphragm expansion vessel Drain water / Readjust pressure	Shut down
379	Pr.exp.vess.min Stop	Group fault alarm	Pump intake pressure is below the set setpoint	Diaphragm expansion vessel defective Quantity of water in the closed pipe system is too low.	Top-up water	Chiller switches off immediately. Alarm is saved. Manual reset.

381 385	Press pump 1 max STOP Press pump 2 max STOP	Group fault alarm	Pressure of the liquid outlet pressure too high	External slide is closed, Filter soiled,	Open external gate valve, clean filter, check overflow valve setting	Pump switches off immediately. Alarm is saved. Manual reset.
382 386	Press pump 1 min STOP Press pump 2 min STOP	Group fault alarm	Pressure of the liquid outlet pressure too low	Flow rate too high, chiller resistance too low, Air in the system	Reduce flow rate, increase chiller resistance, vent the system	Pump switches off immediately. Alarm is saved. Manual reset.
501	AI temp. inlet (VP)	Collective warning message from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Alarm is saved, (From V.2.60) Manual reset.
502	AI coldwater temp outlet	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	All components continue to run. If the temp. inlet sensor is functional, it is switched to this sensor and the setpoint is increased by 6K. Alarm is saved, (From V.2.60) Manual reset.
503	AI coldwater temp outlet 2	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Pump 1 and compressor continue to run, Cold water circuit 2 is blocked, Alarm is saved, (From V.2.60) Manual Reset.
504	AI temp. system return	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Free cooling is blocked. All other components continue to run, Alarm is saved, (From V.260) Manual reset.
505	AI ambient temp.	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Free cooling is blocked. All other components continue to run, Alarm is saved, (From V.260) Manual reset.



506	AI Freecooler inlet	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Free cooling is blocked. All other components continue to run, Alarm is saved, (From V.260) Manual reset.
511	AI cold water press	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Alarm is saved, (From V.2.60) Manual reset.
512	AI press. exp. vess.	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Alarm is saved, (From V.2.60) Manual reset.
513	AI pump pressure 1	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Pump 1 & 2 = Consumer pump - Pump 1 switches off, - Pump 2 and compressor continue to run. Pump 1 = Consumer pump Pump 2 = Evaporator pump Chiller switches off. Pump 1 = Consumer pump Pump 2 = Redundant - Pump 1 switches off, - Pump 2 switches on. Alarm is saved, (From V.2.60) Manual reset.

514	AI pump pressure 2	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Pump 1 & 2 = Consumer pump - Pump 2 switches off, - Pump 1 and compressor continue to run. Pump 1 = Consumer pump Pump 2 = Evaporator pump Alarm is not recognised, No reaction up to V 2.58 - Pump 2 and compressor switch off, - Pump 1 runs up to outlet temperature Max Stop continues. From V. 260 Pump 2 = Consumer pump Pump 1 = Redundant - Pump 2 switches off, - Pump 1 switches on. Alarm is saved, (From V.2.60) Manual reset.
515	AI tank pressure	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Chiller switches off immediately, Alarm is saved, (From V.2.60) Manual reset.
521	AI high pressure	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Pumps continue to run, Alarm is saved, (From V.260) Manual reset.
522	AI low pressure	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Pumps continue to run, Compressor (KK) stops immediately Alarm is saved, (From V.260) Manual reset.
523	AI suction gas temp	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Pumps continue to run, Compressor (KK) stops immediately Alarm is saved, (From V.260) Manual reset.

526	AI cool. water temp.	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	Cooling water circuit is blocked. Refrigeration circuit goes to high pressure fault. Alarm is saved, (From V.2.60) Manual reset.
531	AI conductivity	Combined fault from Version 2.60	Sensor defective, sensor break or sensor short-circuit	Sensor defective, sensor break or sensor short-circuit	Check electrical connections of the sensor, check sensor using the characteristic curve	all components continue to run EV demineralization closes. Alarm is saved, (From V.2.60) Manual reset.
591	AI coding resistor	not in collective fault, omitted from Version 2.60	Coding resistor is missing	Coding resistor is missing	Check coding resistor	Chiller only continues to run with one compressor. Manual rest. (Up to V. 2.59)
592	Coding changed	Collective fault, omitted from Version 2.60	Coding error	The coding resistor measures a different encoding since the last switch-on (number of compressors)	Coding resistor defective, not connected, check the contact	Chiller only continues to run with one compressor. Alarm is saved. Manual reset. (Up to V. 259)
602	DI phase monitoring	Combined fault from Version 2.60	Phase monitoring has tripped	Error in relation to phase sequence, phase failure, undervoltage and asymmetry	Check feed	Chiller switches off immediately. Alarm is saved, (From V.2.60) Manual reset.
611	DI mpcb Pump 1	Group fault alarm	Motor protection switch has tripped	Motor current above the permissible range, Motor runs only on two phases, direction of rotation, poor contact at clip points, Winding fault, earth fault, rotor blocked.	Check the motor power consumption, check the operating point, check the electrical connection of the components	Pump 1 & 2 = Consumer pump - Pump 1 switches off, - Pump 2 and compressor continue to run. Pump 1 = Consumer pump Pump 2 = Evaporator pump Chiller switches off. Pump 1 = Consumer pump Pump 2 = Redundant - Pump 1 switches off, - Pump 2 switches on. Manual reset, Alarm is saved.

613	Flow, start pump 1	Group fault alarm	Flow switch did not switch through after the pump start-up phase	Flow too low	Check flow, check shut-off valves, check pump, check the setting of the reed contact at the flow monitor	<p>Pump 1 &amp; 2 = Consumer pump</p> <ul style="list-style-type: none"> <li>- Pump 1 switches off,</li> <li>- Pump 2 and compressor continue to run.</li> </ul> <p>Pump 1 = Consumer pump  Pump 2 = Evaporator pump  Chiller switches off.</p> <p>Pump 1 = Consumer pump  Pump 2 = Redundant</p> <ul style="list-style-type: none"> <li>- Pump 1 switches off,</li> <li>- Pump 2 switches on.</li> </ul> <p>Manual reset,  Alarm is saved.</p>
614	Flow, pump 1 oper.	Group fault alarm	Flow switch did not switch through during the pump operating phase	Flow too low	Check flow, check shut-off valves, check the setting of the reed contact at the flow monitor	<p>Pump 1 &amp; 2 = Consumer pump</p> <ul style="list-style-type: none"> <li>- Pump 1 switches off,</li> <li>- Pump 2 and compressor continue to run.</li> </ul> <p>Pump 1 = Consumer pump  Pump 2 = Evaporator pump  Chiller switches off.</p> <p>Pump 1 = Consumer pump  Pump 2 = Redundant</p> <ul style="list-style-type: none"> <li>- Pump 1 switches off,</li> <li>- Pump 2 switches on.</li> </ul> <p>Manual reset,  Alarm is saved.</p>

615	DI mpcb Pump 2	Group fault alarm	Motor protection switch has tripped	Motor current above the permissible range, Motor runs only on two phases, direction of rotation, poor contact at clip points, Winding fault, earth fault, rotor blocked.	Check the motor power consumption, check the operating point, check the electrical connection of the components	<p>Pump 1 &amp; 2 = Consumer pump</p> <ul style="list-style-type: none"> <li>- Pump 2 switches off,</li> <li>- Pump 1 and compressor continue to run.</li> </ul> <p>Pump 1 = Consumer pump Pump 2 = Evaporator pump</p> <ul style="list-style-type: none"> <li>- Pump 2 and compressor switch off,</li> <li>- Pump 1 runs up to outlet temperature</li> </ul> <p>Max Stop continues.</p> <p>Pump 2 = Consumer pump Pump 1 = Redundant</p> <ul style="list-style-type: none"> <li>- Pump 2 switches off,</li> <li>- Pump 1 switches on.</li> </ul> <p>Manual reset, Alarm is saved.</p>
617	Flow, start pump 2	Group fault alarm	Flow switch did not switch through after the pump start-up phase	Flow too low	Check flow, check shut-off valves, check pump, check the setting of the reed contact at the flow monitor	<p>Pump 1 &amp; 2 = Consumer pump</p> <ul style="list-style-type: none"> <li>- Pump 2 switches off,</li> <li>- Pump 1 and compressor continue to run.</li> </ul> <p>Pump 1 = Consumer pump Pump 2 = Evaporator pump</p> <ul style="list-style-type: none"> <li>- Pump 2 and compressor switch off,</li> <li>- Pump 1 runs up to outlet temperature</li> </ul> <p>Max Stop continues.</p> <p>Pump 2 = Consumer pump Pump 1 = Redundant</p> <ul style="list-style-type: none"> <li>- Pump 2 switches off,</li> <li>- Pump 1 switches on.</li> </ul> <p>Manual reset, Alarm is saved.</p>

618	Flow, pump 2 oper.	Group fault alarm	Flow switch did not switch through during the pump operating phase	Flow too low	Check flow, check shut-off valves, check the setting of the reed contact at the flow monitor	<p>Pump 1 &amp; 2 = Consumer pump</p> <ul style="list-style-type: none"> <li>- Pump 2 switches off,</li> <li>- Pump 1 and compressor continue to run.</li> </ul> <p>Pump 1 = Consumer pump Pump 2 = Evaporator pump</p> <ul style="list-style-type: none"> <li>- Pump 2 and compressor switch off,</li> <li>- Pump 1 runs up to outlet temperature</li> </ul> <p>Max Stop continues.</p> <p>Pump 2 = Consumer pump Pump 1 = Redundant</p> <ul style="list-style-type: none"> <li>- Pump 2 switches off,</li> <li>- Pump 1 switches on.</li> </ul> <p>Manual reset, Alarm is saved.</p>
619	DI mpcb pump freec.	Group fault alarm	Motor protection switch has tripped	Motor current above the permissible range, Motor runs only on two phases, direction of rotation, poor contact at clip points, Winding fault, earth fault, rotor blocked.	Check the motor power consumption, check the operating point, check the electrical connection of the components	<p>all components continue to run</p> <p>Free cooling is stopped</p> <p>Fault is stored and must be reset manually</p>
621	DI compressor 1 mpcb	Group fault alarm	Motor protection switch has tripped	Motor current above the permissible range, Motor runs only on two phases, direction of rotation, poor contact at clip points, Winding fault, earth fault, rotor blocked.	Check the motor power consumption, check the operating point, check the electrical connection of the components	<p>Pumps continue to run</p> <p>the faulty compressor (KK) stops immediately</p> <p>the other compressors continue to run</p> <p>Fault is stored and must be reset manually</p>

627	DI high-pr. limiter	Group fault alarm	High-pressure limiter has tripped.	Unable to remove the waste heat of the refrigeration circuit.	Clean the condenser and filter. Check the function of the fan. Check the cooling water circuit. Install the cover panels. Press the Reset button and acknowledge at the display.	Pumps continue to run, Compressor (KK) stops immediately Fault is stored and must be reset manually
631	DI mpcb fan 1	Group fault alarm	Motor protection switch has tripped	Motor current above the permissible range, Motor runs only on two phases, direction of rotation, poor contact at clip points, Winding fault, earth fault, rotor blocked.	Check the motor power consumption, Check the operating point, check the electrical connection of the components	Pump and compressor continue to run Compressor switches off via HP.  Fault is stored and must be reset manually
632	DI fan 1 fault	Group fault alarm	Internal monitoring of the fan has tripped.	Motor runs only on two phases, direction of rotation, poor contact at clip points, Winding fault, earth fault, rotor blocked.	Check the motor power consumption, check the electrical connection of the components, check for mechanical blocking,	Pump and compressor continue to run Compressor switches off via HP.  Fault is stored and must be reset manually.
641 643	DI mpcb tank heating	Group fault alarm	Circuit breaker has tripped.	Current above the permissible range, poor contact at clip points due to soiling or corrosion, Short-circuit between the heating rods, earth fault.	Check the electrical connection to the components, test for short to earth	all components continue to run Tank heater is deactivated  Fault is stored and must be reset manually
642 644	DI STP tank heating	Group fault alarm	Safety temperature limiter of the tank heating has tripped	Tank temperature is too high, no water in tank, Trigger point of STP incorrectly set.	Check the tank temperature, check the level, check the tripping point of the STP	all components continue to run Tank heater is deactivated  Fault is stored and must be reset manually

III. II. Maintenance intervals in accordance with the VDMA

	Explanation	Annual	Six-monthly	As required	Remark
	<b>Compressor</b>				
1	Visual inspection for dirt, damage and corrosion	x		x	
2	Check fixing, check running noises	x			
3	Measure the intake pressure	x			
4	Measure the suction gas temperature upstream of the compressor	x			
5	Measure the compression end temperature at the discharge port	x			
6	Check oil level	x			
7	Check the acid content of the oil (acid test)			x	
8	Oil change			x	
9	Check that the crankcase heater is working	x			
10	Check that the output control is working	x			
11	Check the refrigerant side for leaks.	x			
12	Check high/low pressure switching equipment	x			
	<b>Air-cooled condenser</b>				
20	Visual inspection for dirt, damage and corrosion	x		x	
21	Measure the condensing temperature	x			
22	Measure the refrigerant side supercooling temperature at the condenser outlet	x			
23	Measure the medium temperature at condenser inlet and outlet	x			
24	Check that the condensation pressure control is functioning properly	x			
25	Check the refrigerant side for leaks.	x			
	<b>Evaporator</b>				
30	Visual inspection for dirt, damage and corrosion	x			
31	Measure refrigerant overheating temperature	x			
32	Measure the medium temperature at the evaporator inlet and outlet	x			
33	Measure the anti-freeze temperature (freezing point) of the heat transfer media	x			
34	Check the water and refrigerant side for leak	x			



	Explanation	Annual	Six-monthly	As required	Remark
	<b>Parts in the refrigeration circuit/water circuit</b>				
40	Visual inspection for dirt, damage and corrosion	x	x		
41	Check insulation for damage	x			
42	Check filter dryer for blockage	x			
43	Replace filter dryer			X	If components in the refrigeration circuit are replaced
45	Check all pipes carrying refrigerant for corrosion and damage	x			
	<b>Fans</b>				
50	Visual inspection for dirt, damage and corrosion	x		x	
51	Check fixings and bearings	x			
52	Check flexible connection for tightness (electrical connection)	x			
	<b>Pump and piping</b>				
60	Visual inspection for dirt, damage and corrosion	x			
61	Check fixings and bearings	x			
62	Check the safety function of the safety switching	x			
63	Check pump/mechanical seal for leaks	x		x	
	<b>Water filters</b>				
70	Visual inspection for dirt, damage and corrosion	x		x	
71	Clean filters	x		x	
72	Check filters for damage	x			

No.	Explanation	Annual	Six-monthly	As required	Remark
	<b>Membrane expansion vessel</b>				
80	Visual inspection for dirt, damage and corrosion	x			
81	Check fixing	x			
82	Check initial pressure	x			
	<b>Control cabinet</b>				
90	Visual inspection for dirt, damage and corrosion	x		x	
91	Check fixing	x			
92	Check all threaded connections	x			
93	Check all indicator lights and error messages	x			
94	Check that the temperature and pressure sensors are functioning properly	x			
95	Check the function of the motor protection switches	x			
96	Check 24 VDC and supply voltage	x		x	
97	Check control cabinet heater	x			
99	Check control cabinet filter and if necessary replace/clean	x			
	<b>Documents and labelling</b>				
110	All documents such as operating instructions, diagrams, circuit plans, system log are present	x		x	
111	Rating plate and labels are clearly legible	x		x	
	<b>Battery - time/date</b>				
120	Battery			x	Every 5 years

#### IV. Product registration

PDF download at: [www.kkt-chillers.com/service/produktregistrierung](http://www.kkt-chillers.com/service/produktregistrierung)

## Produktregistrierung



alt-deutschland GmbH  
Industriestraße 3 · 06359 Kasendorf · Deutschland  
[www.kkt-chillers.com](http://www.kkt-chillers.com)

### Details zum Chiller\*1

Typ	
SAP-Nr.	
Baujahr	
Serien-Nr.	
Datum der ersten IBN [TT MM JJJJ]	

### Zuständiger Servicepartner\*2

- Lokale Firma  
 Serviceangebot von KKT chillers wird gewünscht

### Details des Endkunden

Produkt des Kunden	
Firmenname	
Straße	
PLZ / Stadt	
Bundesland	
Aufstellort	

### Zuständige Kontaktperson

Name	
Telefon (Handy)	
E-Mail	

### Technische Rückmeldung

- Der Chiller ist waagrecht, falls erforderlich schwingungsgedämmt aufgestellt.  
 Die Schmutzfänger im System sind nach dem Spülen gereinigt worden.  
 Das Kreislaufwasser entspricht den Vorgaben der Bedienungsanleitung, eventuell erforderliche Wasserzusätze (Frostschutzmittel, Biozid, ...) sind beigemischt.  
 Chiller weist keine Fehler auf.

# 24/7

Customer Support

Service-Hotline

+49 9228 9977 7190

Das ausgefüllte Formular senden Sie bitte an:

+49 9228 9977 7474 oder [service@kkt-chillers.com](mailto:service@kkt-chillers.com)

KKT chillers nutzt diese Informationen zur Weiterverarbeitung Ihrer Produktregistrierung. Schreiben Sie daher bitte leserlich! Herzlichen Dank! Ihr KKT chillers Team.

\*1 = Die Details zum Chiller finden Sie am Typenschild des Gerätes.

\*2 = Zuständig für Wartungen und Serviceeinsätze am Chiller.

Produktregistrierung\_20150721